

<b>Digiview</b> <b>Atomic Clock with AM/FM Radio</b>  (RC402W) USER MANUAL	<b>TABLE OF CONTENTS</b>	
	INTRODUCTION	3
	ABOUT HIDEKI ELECTRONICS	3
	PRODUCT FEATURES & OVERVIEW	3
	BATTERY INSTALLATION	8
	WWVB RADIO CONTROLLED TIME	8
	ATOMIC CLOCK	9
	TIME AND CALENDAR WINDOWS	10
	ALARMS SETTINGS	11
	DIGITAL AM FM RADIO	12
	SNOOZE & BACKLIGHT	13
	PRECAUTIONS	13
	FCC STATEMENT	14
	DECLARATION OF CONFORMITY	15
	STANDARD WARRANTY INFORMATION	16

**INTRODUCTION**  
 Thank you for selecting the Digiview Atomic Clock Radio. This product combines an Atomic Clock with AM/FM Radio. This device includes precise time keeping and perpetual calendar that you can use from the comfort of your home.

In this package you will find:

- One Atomic Clock Radio
- One AC adapter
- One User Manual
- One Quick Start Guide

Please keep this manual handy as you use your new item. It contains practical step-by-step instructions, as well as technical specifications and precautions you should know.

**ABOUT HIDEKI ELECTRONICS**  
 Visit our website (www.digiviewtime.com) to learn more about Hideki Electronics precise projection time pieces, environmental products and weather monitoring devices. The website also includes important information about extended warranty programs and other useful facts.

**PRODUCT FEATURES**  
**AM/FM Radio**

- AM/FM radio station tuning
- Radio alarm

**Atomic Clock**

- Precise time and date set via RF signals from the US Atomic Clock
- Calendar displaying date with month and day in English, Spanish, French, German and Italian

• 12 or 24 hour time format

- Dual crescendo time alarm with programmable snooze
- LED backlight

**PRODUCT OVERVIEW**

**FRONT VIEW**

**A. ATOMIC TIME** • Displays time with seconds and US map indicating Time Zone

**B. CALENDAR** • Displays calendar format in month-date format

**C. WEEKDAY** • Displays day of the week abbreviation in 5 languages

**D. RECEPTION TOWER** • Displays the strength of atomic time reception

**E. DUAL ALARMS** • Displays alarm 1 and alarm 2's activation

**SNOOZE & BACKLIGHT**

- Dual crescendo time alarm with programmable snooze
- LED backlight

**PRECAUTIONS**  
 This product is engineered to give you years of satisfactory service if handled carefully. Here are a few precautions:

- Do not immerse the unit in water.
- Do not clean the unit with abrasive or corrosive materials. They may scratch the plastic parts and corrode the electronic circuits.
- Do not subject the product to excessive force, shock, dust, temperature, or humidity, which may result in malfunctions, shorter lifespan, damaged batteries, and damaged parts.
- Do not tamper with the unit's internal components. Doing so will invalidate the warranty and may cause damage. The unit contains no user-serviceable parts.
- Use only fresh batteries. Do not mix new and old batteries.
- Read the user's manual thoroughly before operating the unit.

**DECLARATION OF CONFORMITY**  
 Name: Hideki Electronics, Inc.  
 Contact Person: Mr. James Boyle  
 Address: 7865 SW Molokai, Tualatin, OR 97062  
 Telephone No: 1 503 612 3395  
 declare that the product  
 Product No: RC402W  
 Product Name: AM/FM Clock Radio  
 Manufacturer: Hideki Electronics Ltd.  
 Address: Unit 2304-06, 23F Riley House, 88 Lei Mak Road, Kwai Chung, New Territories, Hong Kong  
 is in conformity with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
 This device may not cause harmful interference.

**SPECIFICATIONS**  
**Radio**  
 AM frequency: 540 to 1700 kHz  
 FM frequency: 87.5 to 108.1 MHz  
**Time**  
 12/24 hour display in 1h, mm format  
 Date format: month - day  
 User-selectable US Time Zones: PST, MST, CST, EST  
 Day of the week: User-selectable in 5 languages- English, Spanish, French, German or Italian  
 Dual 4 minutes crescendo alarm  
 LED backlight: 5 seconds on battery power  
**Power**  
 4 AA size (UM 3) 1.5V batteries (not included)  
**AC/DC adapter**: 6V, 120mA (not included)  
**Dimensions**  
 6.85(L) x 3.4(H) x 4.31(D) inches

**FCC STATEMENT**  
 This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modification to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
 NOTE: This equipment had been tested and found to comply with the limits for a Class B Digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful

DIGIVIEW RC402W MANUAL (ENG)  
 SIZE: W6.8 X H3.4 (mm)  
 BY WING TSUI 11/03/09

2

3

4

13

**F. AM RADIO** • Displays the radio station from a band range of 540 to 1700kHz

**G. FM RADIO** • Displays the radio station from a band range of 88 to 108 MHz

**REAR VIEW**

**H. AC/DC ADAPTOR INPUT** • Connects clock to the power outlet through the AC to 6V DC adapter provided

**L. AM/FM RADIO SWITCH** • Selects AM or FM radio frequency

**J. RADIO ALARM SWITCH** • Selects Radio or Buzzer alarm

**K. WAVE BUTTON** • Entances the clock to receive the atomic time signal

**L. TIME SET BUTTON** • Sets the current time and alarm time manually

**M. RADIO ON/OFF SWITCH** • Turns the radio on and off

**N. DOWN (-) BUTTON** • Decreases all function parameters  
 Activates a language selection mode for the day of the week

**O. UP (+) BUTTON** • Increases all function parameters  
 Activates US Time Zone selection  
 Selects 12 or 24 hour time display format

**P. ALARM BUTTON** • Activates or deactivates alarm 1 and alarm 2

**Q. LIGHT/SNOOZE BUTTON** • Activates LED backlight and snooze

**SIDE VIEW**

**R. LIGHT ON/OFF SWITCH** • Activates continuous backlight when AC adapter is connected

**S. TUNNING KNOB** • Selection of the desired frequency

**T. VOLUME KNOB** • Selection of the desired sound volume

**BOTTOM VIEW**

**U. TIME ZONE SWITCH** • Selection of the desired time zone

**BATTERY INSTALLATION**

- Open the battery compartment door
- Install batteries (UM 3 or "AA" size 1.5V) matching the polarity as shown in the battery compartment.
- We recommend using alkaline batteries
- Avoid using rechargeable batteries. (Rechargeable batteries cannot maintain correct power requirements).
- Replace the battery compartment door.
- Connect 6V AC/DC adapter provided to the main display unit and plug into the power outlet.

**WWVB RADIO CONTROLLED TIME**  
 The NIST (National Institute of Standards and Technology) radio station (WWVB) is located in Ft. Collins, Colorado. It transmits an exact time signal continuously throughout the most of the continental United States at 60 KHz frequency. The Atomic Clock in your radio can receive this WWVB signal through the internal antenna from up to 2,000 miles away. Due to the nature of the Earth's atmosphere, reception can be limited during the daylight hours. The radio controlled clock will search for an alternate station that receives the atomic time signal from the NIST Atomic clock in Boulder, Colorado. The WWVB tower icon on the unit's display will flash indicating a radio signal reception from the WWVB station. If the tower icon is not fully lit, or if the time and date are not set automatically, please consider the following:

- During night time hours, atmospheric disturbances are typically less severe and radio signal reception may improve. A single daily reception is sufficient enough to keep the clock accuracy within 1 second.

interference in a residential installation. This equipment, installed and used in accordance with the instructions, may cause harmful interference to radio communications. There is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to improve or correct turning the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

**DECLARATION OF CONFORMITY**  
 Name: Hideki Electronics, Inc.  
 Contact Person: Mr. James Boyle  
 Address: 7865 SW Molokai, Tualatin, OR 97062  
 Telephone No: 1 503 612 3395  
 declare that the product  
 Product No: RC402W  
 Product Name: AM/FM Clock Radio  
 Manufacturer: Hideki Electronics Ltd.  
 Address: Unit 2304-06, 23F Riley House, 88 Lei Mak Road, Kwai Chung, New Territories, Hong Kong  
 is in conformity with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
 This device may not cause harmful interference.

This device may accept any interference received, including interference that may cause undesired operation.

**STANDARD WARRANTY INFORMATION**  
 This product is warranted from manufacturing defects for one year from the date of retail purchase. It does not cover damages or wear resulting from accident, misuse, abuse, commercial use, or unauthorized adjustment and repair. Note that online product registration is required to ensure valid warranty protection.  
 To register your product, go to our Company website at: [www.digiviewtime.com](http://www.digiviewtime.com). Click Online Product Registrations under the Customer Service menu. Should you require assistance with this product and its operation, please contact our **Customer Service Hotline 1 866-443-3843**. Please direct all returns to the place of the original purchase. Should this not be possible, contact Hideki Customer Service Hotline for assistance and to obtain a Return Merchandise Authorization (RMA). Returns without a return authorization will be refused. Please retain your original receipt as you may be asked to provide a copy for proof of purchase.  
 Hideki Electronics, Inc. reserves the right to repair or replace the product at our option.  
 Copyright (2007) Hideki Electronics Inc. All Rights Reserved. The Honeywell Trademark is used under license from Honeywell Intellectual Properties Inc. Honeywell International Inc. makes no representations or warranties with respect to this product.  
 All user manual contents and information are subject to change. (Print Date: 1 Aug 2007)

**TIME AND CALENDAR WINDOWS**  
 The Atomic Clock Radio displays time in an hour-minutes-seconds format in the **Time Window**. The date is displayed in month-date format next to the day of the week in the **Calendar Window**.

**MANUAL SETTINGS**  
 If desired, the time, date and other available parameters can be programmed manually. It is necessary to set your Time Zone manually.

**TIME ZONE**

**Option 1**

- Slide the Time Zone switch inside the battery compartment to the desired US time zone position.

**Option 2**

- Enter the US Time Zone programming mode by pressing and holding the **UP (+)** button for 3 seconds.
- Keep holding **UP (+)** button until the desired time zone (Pacific, Mountain, Central or Eastern) is highlighted on the unit's display map in the **Time Window**.
- Release the **UP (+)** button and the desired Time Zone will be selected.

**CLOCK**

- Press and hold **TIME SET** button for 3 seconds until the hour digits in the **Calendar Window** will flash.
- Press **UP (+)** or **DOWN (-)** adjusting a correct hour.
- Press **TIME SET** to confirm and move to the next parameter - the minute digit will flash.
- Press **UP (+)** or **DOWN (-)** adjusting the current minute and then press **TIME SET** to confirm - the year digit will flash.
- Press **UP (+)** or **DOWN (-)** adjusting the year and then press **TIME SET** to confirm - the month digit will flash.
- Press **UP (+)** or **DOWN (-)** adjusting the month and then press **TIME SET** to confirm - the date will flash.

• Press **UP (+)** or **DOWN (-)** adjusting the date and then press **TIME SET** to confirm that the last parameter is set

- To select either 12 hour or 24 hour clock operation, simply press the **UP** button

**DAY OF THE WEEK LANGUAGE**

- Press and hold **DOWN (-)** button for 3 seconds to enter the day of the week language programming mode: the default language abbreviation will appear (example - EN - is for English)
- Continue holding **DOWN (-)** button until the desired day of the week language abbreviation is displayed
- Release the **DOWN (-)** button and the day of the week will be displayed in selected language

**ALARMS SETTING**  
 The Atomic Clock Radio has two time alarms, AL 1 and AL 2. The alarms are activated when their respective bell icon is displayed. When triggered, they will sound at the set time and the alarm icon will flash. Also, you can select the alarm sound, either radio or beep sound, by switching to the desired position.

**BELL ALARM SETTING**

- Slide the alarm switch to the **BUZZER** position. Press **ALARM** button, the alarm icon will be shown on the display.
- Then, press **TIME SET** button, "AL 1" will be displayed under the US map.
- Press and hold the **TIME SET** button for 3 seconds again - the hour digit will flash.
- Enter the hour parameter by using **UP (+)** or **DOWN (-)** button.

• Press the **TIME SET** button again, the minute digits will flash.

- Enter the minutes parameter by using **UP (+)** or **DOWN (-)** button.
- Press the **TIME SET** button one last time to confirm the setting.

Use the same procedure for setting the time for **ALARM 2**.

**RADIO ALARM SETTING**

- Slide the alarm switch to the **RADIO** position.
- Adjust the radio station at the corresponding band range.
- Follow the same procedure as **BELL ALARM SETTING**, the radio will be turned on at the pre-set time.

**HOW TO STOP AN ALARM**

- Press the **ALARM** button, the alarm will be disabled and the alarm icon will disappear from the display.

**DIGITAL AM/FM RADIO**  
 The band range of **AM** and **FM** Radio operate from 540 to 1700 kHz and from 87.5 to 108.1 MHz respectively.

**GENERAL OPERATION**

- Slide the **RADIO** switch to turn on the radio.
- Rotate **TUNNING** knob to search the desired radio station.
- Rotate **VOLUME** knob to adjust the desired volume.
- If the reception is weak, try to extend the wire antenna horizontally to improve the reception.
- Slide the **RADIO** switch to turn off the radio. The radio function will be automatically off when the low battery indicator is displayed. Replace old batteries or connect to AC adapter.

15

16

• Make sure the unit is positioned at 8 feet (2 meters) distance from any interference source such as a TV, computer monitor, microwave, etc.

- Within concrete wall rooms such as basements or office buildings, the received signal may be weakened. Always place the unit near the window for better reception.

**ATOMIC CLOCK**  
 Immediately after battery installation, the clock will beep and display all available LCD segments for a moment. Immediately the atomic time signal receiver will start searching for the atomic time signal. It usually takes between 5-8 minutes to synchronize the clock.

**SNOOZE**: Do not press any buttons on the unit during auto search as it may interrupt product's operation, and you will need to start the set up procedure again. If the reception is successful and the atomic time signal is received, the date and time will be set automatically, and the **IP** icon will appear on the display.

**NOTE**: It is necessary to set your Time Zone, the default zone is a Pacific Standard Time (PST). (Refer to the MANUAL SETTINGS section)

If the initial reception was not successful and the time signal has not been synchronized in the first 8 minutes, you may use the **WAVE** button to set the time and date manually. (Refer to the MANUAL SETTINGS section). After the clock is set manually, place it by the window for the better reception. The atomic time receiver will continue to search for the atomic time signal daily each hour between 1:00 am and 4:00 am.

**NOTE**: Allow at least 24 hours for the atomic time receiver to pick up the signal. In some cases, depending on the location, it may take up to 72 hours.

11

12

13

14