




INSTRUCTION MANUAL

Water-cooled

AIR COMPRESSOR

HV2/210



April 2002

Sperre Industri AS
Tel +47 70 16 11 00
Fax +47 70 16 11 10
E-mail: industri@sperre.com

Sperre Rotterdam BV
Tel +31 180 463 299
Fax +31 180 463 264
E-mail: rotterdam@sperre.com

Sperre Asia PTE LTD
Tel +65 763 63 00
Fax +65 763 18 11
E-mail: asia@sperre.com

**Sole suppliers of
genuine spare parts**



INTRODUCTION

The purpose of this handbook is to describe the design and function of the compressor and to provide basic instructions for inspection and maintenance of the equipment.

To ensure proper installation, operation and maintenance from the very beginning, it is essential that the operator should read this handbook with care and attention.

The maintenance intervals and certain technical details given in this handbook are mean values based on experience. These values may vary depending upon the operating conditions of the individual compressor.

The manufacturer disclaims liability for damage due to unskilled operation or improper maintenance of the equipment.

Keep the compressor in good mechanical order, and remember that proper preventive maintenance of the equipment will reduce the risk of damage and unnecessary shutdowns.

The manufacturer reserves the right to amend technical specifications without prior notice.

ELLINGSØY, April 2002
SPERRE INDUSTRI A/S

CONTENTS	Page
1. ORDERING REPLACEMENT PARTS	2
2. DESCRIPTION OF COMPRESSOR	2
2.1. Design	2
2.2. Safety equipment	3
3. INSTALLATION AND OPERATION	3
3.1. Installation instructions	3
3.2. Cooling water system	3
3.3. Starting up	4
3.4. Operation	4
3.5. Stopping	4
4. FAULT TRACING	5
5. INSPECTION AND MAINTENANCE	6
5.1. Maintenance schedule	6
5.2. Valves	7
5.3. Lubricating oil system	8
5.4. Bearings	8
5.5. Piston and piston rings	9
5.6. Flexible coupling	9
5.7. Coolers	10
5.8. Filters	10
6. TECHNICAL DATA	11-12
7. REPLACEMENT PARTS LIST	13-14
8. ILLUSTRATIONS	15-18
9. ILLUSTRATIONS FOR REPLACEMENT PARTS LIST	19-20

1. ORDERING REPLACEMENT PARTS

A list of replacement parts and drawings of the various components will be found at the end of this handbook.

The following information must be given when ordering spares.

- A. COMPRESSOR TYPE
- B. COMPRESSOR SERIAL NUMBER
- C. PART NUMBER AND DESCRIPTION
- D. QUANTITY ORDERED
- E. RATED WORKING PRESSURE OF COMPRESSOR

The type designation (A) and serial number (B) are shown on the rating plate which is fixed to the crankcase.

The rating plate is shown in Fig. 1.

Please note that the manufacturer does not supply oversize or undersize parts, or unmachined parts for further machining and fitting.

The manufacturer disclaims all liability for damage due to the use of non-genuine replacement parts.

Order for replacement parts should be sent to:

Address:	SPPERRE INDUSTRI AS	E-mail:	industri@sperre.com
	6057 ELLINGSØY	Web address :	http://www.sperre.com
	NORWAY	Phone:	+ 47 70 16 11 00
		Fax	+ 47 70 16 11 10

2. DESCRIPTION OF COMPRESSOR

2.1 Design

The machine covered by this instruction book is a single cylinder, 2-stage single-acting watercooled air compressor. The design principle is shown in the cross-sectional drawing Fig. 2.

The first stage of the compressor is the low-pressure stage (LP) and the second is the high-pressure stage (HP). Air circulation through the compressor is shown in Fig. 3. The letters indicate:

- A. Suction filter
- B. LP suction valve
- C. LP delivery valve
- D. LP safety valve
- E. LP cooler
- F. HP suction valve
- G. HP delivery valve
- H. HP cooler
- I. HP safety valve

All bearings are pressure lubricated by a gear pump fitted to the end of the crankshaft.

Two replaceable tube-type coolers are fitted in the compressor cylinder block. The first serves to cool the air after first-stage compression, the second provides cooling after second-stage compression. The cooling water intake and outlet are located so that the water circulates through the cylinder block and ensures efficient cooling of the air and compressor cylinder walls.

The compressor compresses air from atmospheric pressure to rated pressure, with an upper limit of 35 bars.

The compressor is designed for installation together with an electric motor or other drive unit on a well-stiffened base, with a flexible coupling between compressor and motor.

Every compressor is tested before delivery from the factory, and all compressor sets supplied with motor are aligned before dispatch. See chapters 3.1. and 5.6.

This compressor is designed to supply compressed air for engine starting, and for the operation of air power equipment and instruments. It complies with the requirements specified by the classification institutions.

2.2. Safety equipment

The compressor is fitted with two safety valves, one after the first-stage compression and the other after second-stage compression.

The safety valves, which are set at the factory in accordance with the working pressure specified by the customer, ensure that the pressure does not exceed the limit for which the compressor and the compressed air system are dimensioned.

The cylinder block cooling jacket is fitted with a safety plate which will be blow out if the cooling water is subjected to excessive pressure. Use only manufacturer's genuine safety plates to replace blown plates.

A pressure switch is generally included in the automatic control system. This serves to stop the compressor if the lube oil pressure falls below a predetermined minimum.

3. INSTALLATION AND OPERATION

3.1. Installation instructions

Every compressor unit is supplied complete with drawings and specifications showing its dimensions and attachment points. The customer also receives installation instructions giving recommendations for the installation of equipment and piping.

The compressor unit should be installed in a location where the air is not excessively warm. Warm intake air reduces the capacity of the compressor. Normally, the ambient temperature for electrical equipment should not exceed 45°C. The compressor unit bedplate should lie plane to its foundation. After the unit is installed, check the alignment of compressor and motor. The procedure is shown in Fig.4.

Use vernier callipers or inside micrometer callipers to check the distance (W) (Fig.4). This should be the same around the whole circumference of the coupling.

Using a micrometer (A), check the radial misalignment between the coupling halves as shown in Fig.4. The maximum micrometer reading (A) should be as illustrated in Fig. 4.

Even if the unit has been installed on vibration dampers, an alignment check is to be recommended after installation.

Piping should be so installed that there is no risk of water pockets.

Other equipment should not be installed around the compressor unit in such a way that inspection and maintenance operations may be hampered.

3.2. Cooling water systems

It is of the greatest importance to the operation and life of the compressor that a good and reliable supply of cooling water is ensured. The quantities of cooling water required are given in Table T.1. These specifications apply to both seawater and freshwater cooling.

Whether the compressor is connected to a central cooling system or has its own separate cooling water pump, it is important to ensure that the cooling water is circulating properly. In this connection it is not sufficient simply to check that the compressor pressure gauge is registering cooling water pressure.

If the cooling water feed temperature is too low, increased internal condensation may result. If this is the case, the cooling water temperature should be increased. If the temperature cannot be increased by recirculation, condensation can be reduced by reducing the supply of cooling water.

The cylinder block cooling jacket is equipped with a thermometer for the monitoring of cooling water temperature.

Recommended cooling water temperatures are given in Table T.2.

3.3. Starting up

Before initial starting up and after long periods out of use, carry out the following operations:

- A. Check the oil level.
- B. Check that the quality of the oil has not been impaired by water or other foreign matter.
- C. Check compressor valves and lubricate the cylinder with oil.
- D. Turn over the compressor by hand, with the suction valve relieved by means of the manual valve opener.
- E. Check cooling water circulation.
- F. Check that the air line cock between the compressor and the air reservoir is open.
- G. Open the manual drain cocks on the water trap.
- H. Start the compressor.
- I. If everything is operating normally, close the drain cocks and set the valve opener in the operating position.
Allow the compressor to run for a few minutes before loading it to maximum working pressure.

3.4. Operation

During normal operation, pressures and temperatures should be as shown in Table T.2. Some of the values, which are directly affected by local conditions, may deviate slightly from the figures in the table.

Operation of the compressor is normally monitored by the automatic features of the starting equipment, e.g. pressure switch monitoring of lube oil pressure and thermostat monitoring of cooling water temperature. However, additional regular checking of operation and automatic functions is recommended.

Some water from the compressed air will always condense in the system. The compressor is fitted with drain cocks after the HP and LP coolers. If these are not automatically controlled, they must be drained *regularly* by hand. Also, the oil and water traps should be regularly drained by hand, unless this function is performed by an automatic draining system.

Special water traps to collect condensate after the LP cooler can be supplied to order, by the manufacturer.

3.5. Stopping

Stopping the compressor manually for short periods:

- A. Operate the manual valve opener to relieve the LP suction valve.
- B. Open the water trap drain cocks.
- C. Stop the compressor.

If the compressor is to be shut down for a long period, e.g. when a ship is to be laid up, the procedure is as follows:

- AA. Lubricate compressor valves, non-return valves, cylinder walls and exposed crankshaft surfaces with corrosion-inhibiting oil, suitable for the envisaged period of shutdown.
- BB. If there is any risk of frost, drain the cooling water from the compressor.
- CC. Drain off old oil, clean the sump and refill with new oil.
- DD. Set the manual valve opener in the horizontal position to relieve the load on the suction valve.
- EE. Turn over the compressor manually once a month.
- FF. The starter cabinet and other electrical equipment should also be protected from damage by corrosion.

4. FAULT TRACING

The following are some of the faults that may arise in operation.

A. Compressor capacity is low and/or compressor not supplying full pressure.

<i>Possible cause</i>	<i>Remedy</i>
Dirty, damaged or worn valves	Clean and check all valves. Replace defective parts.
Sticking piston rings	Dismantle rings. Clean grooves and rings. Replace defective parts. When reinstalling, lubricate cylinder walls with oil.
Leaking safety valves	Overhaul safety valves, adjust to correct lifting pressure.
Defective gasket between crankcase and cylinder block	Replace gasket.
Air filter blocked	Clean filter.

B. LP safety valve blows.

<i>Possible cause</i>	<i>Remedy</i>
HP valves damaged or dirty	Check and clean valves. Replace defective parts.

C. HP safety valve blows.

<i>Possible cause</i>	<i>Remedy</i>
Air line shut-off cock closed.	Open shut-off cock.
Non-return valve blocked	Remove and clean non-return valve. Replace defective parts.

D. Valves require maintenance too frequently.

<i>Possible cause</i>	<i>Remedy</i>
Overheating	Check cooling water circulation and temp. Inspect coolers and clean if necessary.

Dirty intake air	Check suction filter.
Inferior lube oil	Change the lube oil type. See list of recommended types in this handbook. Manufacturer can supply further information.
Incorrect tightening of compressor valves	Tighten valve to specified torque. clamping screws to specified torque.

E. Overheating or knocking in crankcase.

<i>Possible cause</i>	<i>Remedy</i>
Defective bearings	Inspect bearings, check clearances.
Insufficient lube oil or lube oil contaminated with water	Drain sump, clean and add new oil.
Binding crankshaft bearing	Check bearing clearances. Replace defective parts.

F. Overheating and scoring of piston.

<i>Possible cause</i>	<i>Remedy</i>
Piston or gudgeon pin bearing incorrectly fitted	Replace defective parts, check piston clearances, piston ring clearances and gudgeon pin bearing.
Deficient cooling	Check cooling water circulation and temperatures.

G. Excessive lube oil consumption.

<i>Possible causes</i>	<i>Remedy</i>
Piston rings worn out	Replace piston rings.
Defective crankcase breather valve	Replace breather valve.

5. INSPECTION AND MAINTENANCE

IMPORTANT: PERSONAL SAFETY

Before starting any kind of work on the compressor, the electricity supply must be switched off at the starters and also at the main switchboard. Hang a notice on the switch on the main switchboard to show that repairs are in progress.

5.1. Maintenance schedule

Change the lube oil after approximately the first 200 hours of running in. Drain off the oil while it is warm, clean the crankcase before refilling with new oil. When cleaning, it is important not to use rags that may leave threads or fluff in the crankcase.

The following maintenance schedule is intended as a guideline for normal maintenance. However, compressor operating conditions vary widely from installation to installation and it is therefore important to adapt the maintenance schedule to the experience of the individual operator.

<i>Maintenance intervals</i>	<i>Maintenance routine</i>	
Daily	A	Overhaul: - LP delivery valve - HP delivery valve
Every 500 hours	B	Replace: - Lube oil after cleaning crankcase - Lube oil filter
Every 1000 hours	C	<u>Routine D</u>
Every 3000 hours	D	Check: - Big-end bearings - Piston and cylinder walls through valve apertures - Flexible coupling - Safety valves
Every 9000 hours	E	Overhaul: - LP suction valve - HP suction valve - Air filter (clean)
Every 12000 hours	F	<u>Routine E</u>

<u>Routine A</u>		
Check:	- Lube oil pressure - Lube oil - Cooling water circulation and temperatures - Automatic functions - Drain condensate	
<u>Routine B</u>		
Check:	- LP delivery valve - HP delivery valve - Compressor bedplate bolts	
<u>Routine C</u>		
Check:	- LP suction valve - HP suction valve - Cylinder through valve apertures - Pipe connections	
		<u>Routine F</u>
Check:	- Main bearings - Piston, gudgeon pin and rings - Gudgeon pin bearing - Lub oil pump	
		Before ordering replacement parts, please read the instructions for ordering parts.

5.2. Valves

In the parts list and drawings each valve is shown complete, with its own part number, and also dismantled with the part numbers of the individual components.

After overhaul or replacement of parts, assemble the valves in sequence as shown in the drawing of the dismantled valve.

When assembling valves, lubricate the nut and valve bolt and tighten to the torques (in kpm) given below:

Dimension	Minimum	Maximum
M10	2.00	2.45
M12	3.60	4.40
M14	5.70	6.90
M16	9.00	11.00

IMPORTANT:

Before attempting to check compressor valves, loosen the clamping screw on the valve cover before removing the cover.

After inspecting and overhauling valves, it is essential that the clamping screw, which bears against the valve clamping piece and which keeps the valve in place on its seat, should be tightened with an unbrako key to the torque shown in Table T.3.

Overhaul and maintenance of valves

Regular and careful maintenance of valves is essential to the capacity and reliability of the compressor. We therefore recommend overhaul in accordance with the following guidelines:

- A. When cleaning and dismantling the valve, never clamp the valve directly in a vice to loosen the centre bolt nut. A special clamping jig for this purpose, suitable for all valves, is available from the factory on request. A simple makeshift for clamping the valve is to set it in a vice between two pins which fit into the outermost seat slots of the valve.
- B. Clean the valve components and check them carefully.
IMPORTANT: Never use sharp implements on sealing surfaces and plate parts.
- C. Replace all parts that are worn or even slightly scored. Check that all guide pins are in order. Maximum wear limit is 10% of the total thickness of components.
- D. If a valve spring or spring plate shows signs of weak-ness, all springs must be replaced at the same time, because damage can result if some springs operate longer than others. Replacement of all valve springs is recommended after about 5000 hours running time, even if the springs do not look worn.
- E. If there are signs of abrasion or scoring of the valve seat sealing ledges, these must be machined. Most valves are drilled for guide pins, with spare holes for new pins. Guide pins can be driven out by means of a suitable tool. If it proves impossible to remove a broken pin, use one of the spare holes.
- F. To remove the valve centre bolt, mark the centre of the pin with a centre punch and then drill out the pin. Remove the centre bolt. After refitting the bolt, drill a hole for the safety pin, drive the pin securely into place and peen the end to prevent it from falling out.
- G. After completion of machining and careful replacement of guide pins in their respective holes in the valve seating and/or catch plate, check that the ends of the pins do not but against the bottom of the holes in the matching parts.

Use **only** genuine replacement pins and parts.

Assembly of valves demands precision, care and forethought. Make sure that the various parts are correctly located and that the right numbers are installed. Compare with the lists and drawings of parts to ensure that the right number of parts is present. Total lifting heights of valve plates are given in Table T.4.

5.3. Lubricating oil system

The lube oil pump is a gear pump which is normally capable of operating for long periods without maintenance. The pump is directly driven from the end of the crankshaft, and oil pressure is controlled by means of a by-pass valve in the pump. To overhaul, dismantle the mounting flange and pipe connections, and pull the pump out.

An easily replaceable lube oil filter is fitted between the delivery side of the pump and the compressor.

IMPORTANT: Accumulation of condensate in the crankcase may present a serious problem under certain operating conditions, and it is important that the operator should check from the very beginning whether condensate in the lubricating oil is liable to become a problem.

Unless the condensed water emulsifies with the lubricating oil, it will separate out and there is a risk that the compressor will be lubricated with water.

The choice of lube oil is of great importance to the reliable operation of the compressor. The manufacturers have performed extensive tests of lube oils for the oil companies, and the following is a list of lubricants recommended on the basis of these tests.

A list of recommended types of oil is affixed to the compressor on delivery.

Mineral oil	Syntetic oil
BP ENERGOL RC 68	BP ENERSYN RX 100
CASTROL AIRCOL PD 100	CASTROL AIRCOL SN 100
CALTEX RPM COMPR. OIL 68	CHEVRON HD COMPR. OIL 100
ESSO/ EXXON EXXCOLUB 77	DAPHNE MARINE COMPRESSOR 100
FINA EOLAN AC	ELF PRIMERIA SG 100
GENERAL COMPOL A 100	ESSO/EXXON ZERICE S 100
MITSUBISHI COMPR. OIL 100	ESSO/EXXON SYNTESSTIC 68
MOBIL RARUS 427	MOBIL RARUS 827
NYNÄS COMPR. OIL 68	NIPPON OIL CO. FAIRCOL SA100
PHILLIPS COMPR. OIL 68	SHELL CORENA AP 68
SHELL CORENA P 68	STATOIL COMPWAY S 100
	TEXACO SYN STAR DE 100

Further information about lubricants is available on application to the manufacturer.

5.4. Bearings

The compressor has replaceable, two-shell plain big-end and crankshaft bearings. The middle crankshaft bearings serves as an axial guide for the crankshaft.

The gudgeon pin bearings are single shell plain bearings, press-fitted into the little ends. Tolerances and clearances for connecting rod, crankshaft and gudgeon pin bearings are given in Table T.4.

All plain bearings are pressure lubricated.

After inspection or replacement of the big-end bearings it is important to ensure that the bearing does not bind on the crankshaft. It must be possible to turn over the compressor manually.

New two-shell bearings are coated with a running-in compound at the factory.

Dismantling the gudgeon pin bearing from the connecting rod.

- A. Use a hydraulic press or extractor to remove the old bearing shell.
- B. Press in the new bearing shell.
- C. Adjust the fit of the bearing to the gudgeon pin in accordance with Table T.4.

5.5. Piston and piston rings

Dismantle the piston as follows:

LP piston

- A. Remove the cylinder head without dismantling the valves.
- B. Remove the big-end bearing bolts and bearings.
- C. Withdraw the piston and connecting rod from above.

Assembly sequence is the opposite of the above.

HP piston

- AA. Remove the big-end bearing bolts and lower bearing shell. Turn over the crankshaft to top dead centre and then back. The upper bearing shell can now be removed.
- BB. Turn over the crankshaft to bottom dead centre, then withdraw the piston and connecting rod through the crankcase door.

Assembly sequence is the opposite of the above.

5.6. Flexible coupling

The compressor flywheel serves as one coupling half.

Dismantle the coupling

- A. Loosen the nuts on each coupling half and give each one a sharp tap with a hammer before removing them completely. This will cause the bolts to loosen from their conical holes in the coupling halves.
- B. Remove the bolts and take out the flexible coupling. Avoid spilling oil on the flexible coupling.

The coupling half on the motor is keyed and shrunk on to the axle.

Alignment

The principle and values for checking alignment are shown in Fig. 4.

- A. Micrometer/dial indicator
- B. Magnetic base
- C. Flywheel
- D. Coupling half, motor
- E. Flexible coupling

Check the angle (W) by means of inside micrometer callipers or vernier callipers. The distance (W) in mm should be the same around the whole circumference of the coupling halves.

Check parallel misalignment (A) between coupling halves as shown, around the circumference of the coupling halves (C). Values in mm for maximum parallel misalignment are given in Fig.4.

5.7. Coolers

To ensure reliable operation of the compressor it is important to keep the LP and HP coolers free from deposits of carbon and cooling water salts etc. Insufficient cooling causes excessive air temperature and progressively increases the formation of carbon deposits.

The cooling tubes are roller expanded into tube plates at both ends.

The seals at the cooler ends are O-rings, type OF special quality. Use only manufacturer's spares. To remove the tube bundle, first loosen the cooler covers at both ends. The whole bundle can then be withdrawn by means of two guide rods, pushed through the tubes.

Assemble in opposite sequence.

Instal new seals.

If the cooling tubes show signs of severe corrosions or wear, the complete cooler should be replaced.

5.8. Filter

The air filter should be cleaned by means of a good degreasing agent. Blow the filter clean with compressed air and give it a thin coating of compressor oil.

The oil filter should be replaced complete. Replacement every 1000 hours running time is recommended.

6. TECHNICAL DATA

T.1. Coolant flows

Shaft speed rpm.	580	-	725	-	875	-	975
Coolant flow l/min. 7-10 bars..... :	17	-	21	-	26	-	28
Pressure drop across compressor (mm.w.c.)..... :	110	-	180	-	280	-	350
Coolant flow l/min. 15-35 bars..... :	21	-	26	-	32	-	35
Pressure drop across compressor (mm.w.c.)..... :	180	-	280	-	440	-	550

T.2. Recommended pressures and temperatures

Recommended minimum inlet temperature Cooling water	: 30°C
Recommended maximum outlet temperature Cooling water	: 60°C
Recommended temperature difference.....	: 15 - 20°C
Recommended cooling water pressure.....	: 0.5 - 3.0 bars
Recommended lube oil pressure, warm compressor.....	: 2.0 - 0.8 bars
Recommended limit switch setting for lube oil pressure/safety stop.....	: 0.8 bars
Normal working pressure one stage 0-10 bars	: 1.5 - 3.5 bars
Normal working pressure one stage 10-35 bars	: 4.0 - 6.0 bars
Maximum working pressure.....	: 35 bars
Safety valve setting over stage pressure.....	: 10%
Normal temperature outlet air.....	: 30 - 65°C

T.3. Torque table

A - Thread diameter (mm)
 B - Key width
 C - Torque (kpm), clean and lubricated threads
 * - Marker for unbrako screw
 ** - Marker for BSP threads

Component	A	B	C
Cylinder head	M20	30	20
Cooler cover	M16	24	15
Cooler cover	M12	19	8
Valve cover HP and LP	M16	24	15
Valve clamping screw HP and LP	*M20	10	12
Cap lock nut HP and LP	M20	30	10
Big end bearing bolts HP and LP	**1/4	22	9-10
Main bearing studs	M12	19	8
Bearing housing, crankcase	M10	17	4
Cylinder block to crankcase	M22	32	25
Hand hole – Air intake manifold	M12	19	8
Crankcase covers.....	M10	17	4

T.4. Clearances

Suction valve LP Lifting height	(mm).....	: 1.2
Pressure valve LP Lifting height	(mm).....	: 1.2
Suction valve HP Lifting height	(mm).....	: 1.1
Pressure valve HP Lifting height	mm).....	: 1.4
Cylinder/piston clearance LP	(mm).....	: 0.35
Cylinder /piston clearanse HP	(mm).....	: 0.25
Piston/cylinder head clearance LP	(mm).....	: 1.4 - 1.8
Piston cylinder head clearance HP	(mm).....	: 1.4 - 1.8
Crankshaft/guide bearing end clearance	(mm)....	: 0.3 - 0.5
Main bearing/shaft clearance	(mm).....	: 0.08 - 0.12
Crankshaft bearing play	(mm).....	: 0.08 - 0.11
Gudgeon pin bearing play	(mm).....	: 0.03 - 0.04

T.5. Piston rings

Pressure stage	LP	HP
Piston illustration (F.5.).....	B	A
Number of compressor rings.....	2	4
Number of scraper rings.....	2	
Number of oil rings.....	1	1
Min. end clearance S (mm).....	0.80	0.35
Max. end clearance S (mm).....	1.05	0.55
Wear limit S (mm).....	2.05	1.55

T.6. General data

Number of cylinders	: 2
Cylinder diameter LP	(mm).....	: 210
Cylinder diameter HP	(mm).....	: 93
Stroke	(mm).....	: 110
Crankpin diameter	(mm).....	: 63
Crankshaft diameter at bearing	(mm).....	: 63
Gudgeon pin diameter LP	(mm).....	: 40
Gudgeon pin diameter HP	(mm).....	: 40
Number of valves LP	: 2
Number of valves HP	: 2
Oil capacity of sump	(litres).....	: 8

7. Replacement Parts List - Water Cooled Air Compressor - HV2/210

Part No.	Qty.	Description	Part No.	Qty.	Description
1012	1	Crankcase	3696	3	Cap nut - clamping screw
1038	1	Crankcase cover	3697	1	Cap nut - lub. oil pump
1041	1	Crankcase cover - dipstick side	3700	1	Breather valve
1058	1	Bearing housing - flywheel side	3713	1	Air filter unit, complete
1062	1	Bearing housing - lub. oil pump side	3718	1	Air filet insert
1076	1	Flywheel	3722	1	Oil strainer
1103	1	Cylinder block	3728	1	Oil strainer mesh
1153	3	Main bearing shell cups	3731	1	Oil strainer holder
1163	4	Bearing shell cups, pair	3741	2	Clamping screw, HP
1171	1	Cooler cover - Pos. 1	3742	1	Clamping screw, LP
1175	1	Cooler cover - Pos. 3	3746	1	Dipstick
1231	1	Frame - bursting plate	3770	2	Pressure gauge, C.W./lube oil
1255	1	Cylinder head	3771	1	Pressure gauge, LP
1297	1	Air filter duct	3773	1	Pressure gauge, HP
1316	2	Valve cover, HP	3775	2	Spacer
1318	1	Valve cover, LP suction side	3781	1	Thermometer
1319	1	Valve cover, LP delivery side	3783	1	Nipple - thermometer
1330	1	Flywheel nut	3810	4	Seeger ring
1366	1	Non return valve cover	3821	1	Gudgeon pin bearing, LP
1382	1	Coupling flange	3822	1	Gudgeon pin bearing, HP
1414	1	Connecting rod, LP	3832	2	Big-end bearing shell, pair
1415	1	Connecting rod, HP	3852	1	Sealing ring - lub. oil pump
1440	2	Inspection hole cover	3861	1	Sealing ring - main shaft
1441	1	Inspection hole cover with 1/2" hole	3906	5	Valve gasket
1463	2	Clamping piece, HP valve	3909	2	Valve gasket
1471	1	Clamping piece, LP suction valve	3921	2	Main bearing end
1472	1	Clamping piece, LP delivery valve	3922	1	Main bearing guide
1516	1	Counterweight	3925	4	Copper washer
1530	1	Blind plate	3927	8	Copper washer
2012	1	Crankshaft	3928	5	Copper washer
2998	1	Non return valve	3929	22	Copper washer
3245	1	Valve unloader, complete	3930	6	Copper washer
3304	1	Unloader cover	3932	4	Copper washer
3311	1	Unloader cylinder	3934	2	Copper washer
3318	1	Unloader piston	3937	4	Lock washer
3329	4	Big-end bearing bolt	3946	4	Screw - lub. oil pump
3335	4	Big-end bearing nut	3950	2	Screw - pressure gauge panel
3340	4	Big-end bearing split pin	3960	1	Bursting plate
3384	1	Piston, LP	3965	1	Internal lub. oil tube set
3398	1	Piston, HP	3974	4	O-ring - air coolers
3446	1	Connector - pump	3979	1	O-ring - valve unloader
3465	1	Gudgeon pin, LP	4028	2	Gasket - crankcase / cylinder block
3468	1	Gudgeon pin, HP	4033	2	Gasket - crank case cover
3486	2	Oil scraper ring, LP	4034	1	Gasket - bearing housing, oil pump side
3505	4	Compression ring, HP	4035	1	Gasket - bearing housing, flywheel side
3519	2	Compression ring, LP	4053	1	Gasket - air outlet flange
3533	1	Oil ring, HP	4057	2	Gasket - HP valve cover
3544	1	Oil ring, LP	4058	2	Gasket - LP valve cover
3577	1	Ball - lub. oil pump	4059	1	Gasket - lub. oil pump
3583	1	Valve spring - lub. oil pump	4068	4	Gasket - bursting plate
3606	1	Adjusting screw - lub. oil pump	4070	1	Gasket - cylinder cover
3634	1	Oil level gauge glas	4085	1	Gasket - air filter duct
3643	1	Pressure gauge board	4099	3	Gasket - cooler cover
3654	2	Cooler unit	4132	1	Backnut
3677	1	Key	4142	1	T-joint

Part No.	Qty.	Description
4189	34	Stud - crank case covers
4192	16	Stud - inspection hole
4193	4	Stud - bursting disk
4197	6	Stud - main bearing housing
4198	1	Stud - LP separator
4202	10	Stud - cooler cover
4204	2	Stud - cooler cover
4208	16	Stud - valve cover
4209	12	Stud - cooler cover
4215	8	Stud - cylinder block / crank case
4219	6	Stud - cylinder top
4236	4	Nut - drain plate
4237	34	Nut - crank case cover
4238	32	Nut - inspection hatch, cooler cover
4240	44	Nut - cooler cover, valve cover
4242	6	Nut - cylinder top
4253	6	Locknut - main bearings
4257	8	Locknut - cylinder block / crank case
4268	1	Set screw - counter weight
4269	1	Nipple
4271	4	Nipple
4273	2	Nipple
4275	1	Nipple - c.w. inlet
4276	1	Nipple - c.w. outlet
4280	2	Nipple
4294	3	Plug
4296	7	Plug
4297	1	Plug
4298	1	Plug
4361	1	Pressure gauge tube
4364	2	Pressure gauge tube
4367	1	Pressure gauge tube
4372	3	Nipple
4374	1	Reduction nipple
4388	1	Lub. oil tube
4391	1	Lub. oil tube
4407	2	Screw - counterweight
4414	2	Washer - pressure gauge panel
4416	8	Washer - cooler cover
4420	1	Safety valve, HP
4421	1	Safety valve, LP
4433	4	Screw - non return valve cover
4441	1	Lub. oil pump
4446	1	Set screw
4447	1	Set screw
4449	2	Screw
4451	2	Connecting nipple
4471	2	T-joint
4487	6	Coupling bolt
4523	1	Coupling disk
4624	4	Screw - non return valve flange
4673	2	Screw - gudgeon pin bearing
7591	1	Cooler cover - Pos. 2
7593	1	Cooler cover - Pos. 4
7595	1	Separator
7609	1	Cyclone pipe
7620	6	Stud - cooler cover Pos. 2
7645	1	Drain plate


Part No.	Qty.	Description
7648	1	Gasket - drain plate
7651	1	Drain trap
7654	1	Drain nipple
7655	1	Guide pin
7657	1	Plug
7659	1	Cap nut
7660	1	Gasket
7664	4	Stud - drain plate
7665	2	Swivel nipple
7747	6	Stud - cooler cover Pos. 4
7750	2	Plug
7754	1	Nipple

Valve parts:

3012	1	Delivery valve, HP complete
3020	1	Suction valve, LP complete
3021	1	Delivery valve, LP complete
3043	1	Valve gripper, LP complete
3049	1	Suction valve, HP complete
3061	1	Valve seat, HP suction
3062	1	Valve seat, HP delivery
3069	1	Valve seat, LP suction
3070	1	Valve seat, LP delivery
3087	2	Damping plate, LP
3092	3	Valve spring, HP suction
3106	2	Valve plate, HP suction
3109	2	Valve plate, LP valve
3133	2	Valve washer
3135	1	Valve washer
3141	1	Fixing pin
3142	1	Fixing pin
3145	2	Fixing pin
3146	2	Fixing pin
3161	1	Valve catcher, HP suction
3162	1	Valve catcher, HP delivery
3167	1	Valve catcher, LP suction
3168	1	Valve catcher, LP delivery
3181	1	Valve spacer ring
3182	1	Valve spacer ring
3186	3	Valve spacer ring
3187	1	Valve spacer ring
3206	1	Valve bolt, HP suction
3207	1	Valve bolt, HP delivery
3214	1	Valve bolt, LP delivery
3218	1	Valve bolt, LP suction
3237	2	Valve nut
3238	2	Valve nut
3260	6	Valve spring, HP delivery
3265	6	Valve spring, LP suction/delivery


Fig. 1

1 GB

 **SPERRE**
AIR COMPRESSOR


TYPE CAP. m³/h
No. PRESS. Barg
POWER kW SPEED RPM
SPERRE INDUSTRI A/S · N-6057 ELLINGSØY · NORWAY

4 ES

 **SPERRE**
COMPRESOR DE AIRE


TIPO CAP. m³/h
Nº PRES. Bar
POTENCIA kW ROT. min⁻¹
SPERRE INDUSTRI A/S · N-6057 ELLINGSØY · NORUEGA

2 NO

 **SPERRE**
LUFTKOMPRESSOR


TYPE KAP. m³/t
Nr. TRYKK Bar
EFFEKT kW TURTALL min⁻¹
SPERRE INDUSTRI A/S · N-6057 ELLINGSØY

5 FR

 **SPERRE**
COMPRESSEUR D'AIR

TYPE CAP. m³/h
Nº PRESS. Bar
PUISSANCE kW ROT. min⁻¹
SPERRE INDUSTRI A/S · N-6057 ELLINGSØY · NORVEGE

3 DE

 **SPERRE**
LUFTKOMPRESSOR

TYP LEIST. m³/h
Nr. DRUCK Bar
EFFEKT kW DR.ZAHL min⁻¹
SPERRE INDUSTRI A/S · N-6057 ELLINGSØY · NORWEGEN

FIG. 2




FIG. 3




FIG. 4






Fig. 5




HV2/200 – HV2/210 – HV2/219

NOV. 2001




Low pressure suction valve

3020




Low pressure delivery valve

3021



High pressure suction valve

3049



High pressure delivery valve

3012

