

# CUTE FRIENDS SMART PUPPY





# **Battery Installation and Charging**

#### Battery installation (Apply to AAA size battery version)

- 1.Switch off the puppy.
- 2. Open the battery compartment by loosening the screw.(fig.1)
- 3.Put 3 x AAA battery(not included) in the battery compartment as per the polarity shown inside.(fig.2)
- 4.Place back the battery compartment cover.(fig.3)

#### TIPS!

Best performance can be only obtained by using new alkaline batteries.


#### The distance of the second of

- 1.Switch off the puppy.
- 2. Open the battery compartment by loosening the screw. (fig.4)

Battery installation (Apply to 3.7v Li-ion battery version)


- 3.Insert the Li-ion battery(included) plug into the socket, and put the Li-ion battery in the battery compartment as per the polarity shown inside.(fig.5)
- 4. Place back the battery compartment cover. (fig. 6)


# fig.1 MADE IN CHINA













# Charging the battery


1. Switch off the puppy. Open the battery compartment by loosening the screw(fig.4). Unplug the battery plug(fig.7). Insert the battery plug into the charging socket on the USB(fig.8). Insert the USB plug into the USB socket, the charging indicator turns on, the charging process begins(fig.9). 2. Unplug the charging plug after the charging indicator turns off. Charging is completed.

#### TIPS!

- The puppy can operate for about one hour per every one hour charging.
- 2. Before recharging the battery, wait 10-15 minutes for it to cool down.









#### **AWARNING:**

CHOKING HAZARD-Small parts. Not for Children under 3 years.

# **Delivery Contents**

AAA size battery version

-The puppy

-Instruction manual

3.7v Li-ion battery version

-The puppy

-3.7v Li-ion batterv

-Instruction manual

-USB charger wire

# Safety Precautions

-Parents, this toy is recommended for children. To ensure that your child's play is both safe and fun, please review the operating instructions with your children.

-DO NOT pick up moving puppy.

-Keep hands, hair and loose clothing away from the legs when power switch is turned ON.

-Remove battery from the toy when not in use.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



The crossed-out dustbin symbol indicates that batteries, rechargeable batteries, button cells, battery packs, etc, mush not be put in the household waste. Batteries are harmful to health and the environment. Please help to protect the environment from health risks. Tell your children to dispose of batteries properly by taking them to the local collecting points. This way batteries are recycled safely.



#### Waste Electrical and Electronic Equipment(WEEE)

When this appliance is out of use, please remove all batteries and dispose of them separately. Bring electrical appliances to the local collecting points for waste electrical and electronic equipment. Other components can be disposed of in domestic refuse.

TIPS!

Best performance can be only obtained by using new alkaline

batteries.

#### Cautions:

-Non-rechargeable batteries are not to be recharged.

-Rechargeable batteries are to be removed from the toy before being charged.

-Rechargeable battery are only to be harged by an adult.

-Different types of batteries or new and used batteries are not to be mixed.(Transmitter only)

-Only batteries of the same or equivalent type as recommended are to be used.

-Batteries are to be inserted with correct polarity.

-Exhausted batteries are to be removed from the toy.

-The supply terminals are not to be short-circuited.

-Do not mix old and new batteries.(Transmitter only)

-Do not mix alkaline standard(carbon-zinc)or rechargeable (nickel-cadmium) batteries (Transmitter only)

### Care and Maintenance:

-Always remove batteries from the toy when it is not being used for a long period of time.

-Wipe the toy gently with a clean damp cloth.

-This toy is intended for indoor use only.

-Do not submerge the toy into water that can damage the electronic assemblies.

#### Note:

-Parental guidance is recommended when installing or replacing batteries.

-Users should keep and retain this information for future reference.

-Users should keep strict accordance with the instruction manual while operation the toy.

## Battery requirement for AAA size version:

Power Supply : \_\_\_\_ ⊕ ⊖ Rating

: DC6V,1.35W

⊕ Batteries

: 3 x 1.5V "AAA"/LR03/AM4(not included)

# Battery requirement for 3.7v Li-ion battery version:

Power Supply: ==== Battery ratings: DC3.7V

Batteries

: 1 x 3.7V Li-ion Rechargeable Battery Pach(included)

Capacity

: 300 mAh