

# User's Manual

**X mirror**

No.A00

# Contents

Enter the electronic manual-----01

Precautions-----02

Copyright-----03

## **1 Basic operation**

1.1 Enter the main menu interface-----04

## **2 Function Operation(The machine settings, please refer to table )**

2.1 Navigation function operation-----05

2.2 CAR DVR function operation-----06

2.3 Bluetooth function operation-----05

2.4 USB function operation-----11

▶ Video function operation-----11

▶ Music function operation-----12

▶ Pictures function operation-----13

2.5 Electronic compass function operation--14

2.6 MHL Function Operation-----14




## **3 System setup-----15**

(The machine settings, please refer to table )







# Enter the electronic manual

Touch the menu on left side, find **【SETTING】** ---> **【Other】** ---> **【E-INSTRUCTIONS】** button to enter the electronic manual interface.

## ■ Touch icon function description

- ① Touch the icon to enter the corresponding interface.
- ②  Back ---> Back to the main interface
- ③ Numeric Keypad ---> Input corresponding number and click ok to confirm.
- ④  /  ---> Menu up/down page

Enter the corresponding interface, icon description (Touch anywhere on the screen to hide or display)

- 
- ①  Back ---> Back to the main menu
  - ②  /  ---> Up/down page
  - ③  /  ---> Zoom in/out
  - ④ Contents  ---> Back to menu interface

# Precautions

## Safety Precautions

- ❌ To ensure the traffic safety and avoid contravening the traffic regulations, please obey the local laws while the Bluetooth or any other options are working. And do not watch any programs or operate the system during driving.
- ❌ For safety and current operation of the product, the product shall be installed by professional. Do not disassemble or repair the product by yourself to avoid an accident or damage to the product.
- ❌ To avoid electric shock, damage and fire resulting from short-circuit, do not place the product in water or places where are wet.
- ❌ As for car backing, this system works simply as an assistant tool. Our company is not responsible for any potential car backing accidents.

## Notes

- To avoid trouble aroused by rapid operation, when you operate the host unit, please do not operate other functions until the last execution is finished.
- Please turn on/off the machine or press the reset key when system error happened.
- Except volume button, please do not use other functions while making call through Bluetooth.
- Please do not do any other operation on the machine while using the backing camera.

# Copyright

## ★★★★ Copyright

The copyright of this manual is reserved by our company. All rights are reserved. This manual may not be copied, reproduced or translated in whole or in part without the express written permission of our company.

Our company reserves the right to improve the product, and its hardware and software.

This manual is an operating guide, but not the warranty of the product. Our company doesn't guarantee the contents included in this manual.

Since we adhere to the strategy of sustainable development, printing error in the manual, incompliance with latest materials, software upgrade, and product improvement may be performed at any time. The product is subject to change without further notice, and revision will be directly edited to the manual of new edition.




Not all of functions in this e-book are exited for all the modes, different models will configure different functions, please according to the actual models.


**Our company reserves the right of final interpretation for the manual.**

# 1 Basic operation

## 1.1 Enter the main menu interface

### After connect the power:

- 1) press 【  】 icon on rear view screen to open screen/close screen.
- 2) Wave swept from left to right to open screen.
- 3)The screen display the current date information on the right of main interface.
- 4) The main interface was in selected state, only four functions display on the screen.  
Slide or touch 【  /  】 button to change different function menu.
- 5) Main function : **NAVI**、 **CAR DVR**、 **BLUETOOTH**、 **USB(Video/Music/Photo)**、  
**COMPASS**、 **MHL**、 **SETTING** and etc.

Touch  icon to back to main interface.

## 2 Function operation

### 2.1 NAV function operation

In the main menu press the **【NAVI】** button on the left function interface to enter the navigation mode.

This function is available only when connected with navigation module.

In navigation mode only the touch screen functionality of the navigation software will be available .If other functions needed you must exit the navigation mode.

#### ◆ Music function during navigation


When switching to the navigation state from multimedia changer state, you can enjoy music normally. When there is navigation indication, the system will adjust the volume of the music and navigation.

#### ◆ Volume adjustment





Under navigation status and when there is music output,it is to adjust the system volume at this time.  
Under the voice navigation status, it is only for NAV volume adjustment.

## 2 Function operation

### 2.2 CAR DVR function operation

When the top right of the icon bar displays information indicates 【】 (flashing), touch the icon to go to the current video interface, Touch the left analog disc or 【CAR DVR】 into the driving record instrument interface menu.

#### ◆ Recording

- ①  ---> Recording /pause,
- ②  ---> Quick lock button, lock the current playing video
- ③  ---> Captured frame images from video.
- ④  ---> Set interface








---

Can set the 【save video files】 / 【recording quality】 / 【recording resolution】  
【boot record】 / 【Sound Recording】 / 【Recording Format Card】 six options .










## 2 Function operation

### ◆ Playback

- ①  ---> Exception category list
- ②  ---> Full list
- ③  ---> Lock list categories
- ④  ---> Up/down icon
- ⑤  ---> Lock the selected video manually,  
The lock stitch icon will display in front of  
the file.
- ⑥  ---> Delete the selected files
- ⑦  ---> Delete all files in the list

Click the pictures files in the list and  
enter Video interface

---

- ①  ---> Previous /next
- ②  ---> Pause     ---> Play
- ③  ---> Unlock the locked file
- ④  ---> Lock the currently playing file,  
The top left of the screen displays  
“” icon.
- ⑤  ---> Delete the currently playing  
video files.

## 2 Function operation



### 2.3 Bluetooth handsfree function operation

In the main menu press the **【BLUETOOTH】** on the left function interface, button to enter the bluetooth handsfree mode.

**Note:** As the bluetooth modules and software of cellphone with different brands, some functions may be different or even not compatible with other system in actual use, please forgive us for this.

If the bluetooth unconnected, the interface display bluetooth setup interface. On the right side of list display paired and unpaired bluetooth devices. Click unpaired device to pair. After matching, the connection can be reestablished automatically.

#### ◆ Bluetooth device interface

- ① Search ---> Enter search interface.
- ②  ---> Click start search.
- ③ Pair ---> Display bluetooth name and PIN.
- ④  ---> Bluetooth settings, such as change bluetooth name and PIN code , open/close automatic answer, automatic connect, automatic update phonebook.



## 2 Function operation

After the Bluetooth connection is successful, the main title bar will display the phone signal strength and power, as well as the Bluetooth icon is blue.

### ◆ Dial up

After the connection succeed, you can dial number through mobile phone or enter telephone number on the number button from screen.



### ■ Dail interface ---- Icon function description

- ①  ----> Delete
- ② REDIAL ----> Redial
- ③  ----> Dial up


## 2 Function operation

### ◆ Answer the phone


1) When there is outside calling, in any mode, the system will automatically switch Bluetooth handfree interface, and playing music for original mode will turn to incoming ring.

2) Press the “ Answer”, “ hang up ” on the screen to choose answer or reject.


If answer is set up for : automatically answer , after ring for three times, it will automatically connect telephone.


3) During communication, click “ switch ” to switch communication between car amplifier and mobile phone.


### ◆ Phone book


 --->Phone book images appears, the phonebook displays incoming calls, received calls, and missed numbers.

### ◆ Call records

 --->Call history

 --->Call recording

 ---> Missed calls

 --->Refresh

## 2 Function operation

### 2.4 USB function operation

#### Video function operation





In the main menu state, press **【USB】**  
---> **【Video】** to enter Video interface.

Gently touch **【☰】** icon, all the video files from USB will be shown on the left of the screen.

Gently touch the video file name, it will be shown in a small window in the middle of screen, after the video shows for more than 10s without any operation, it will be switched to “full screenstate” automatically.

#### ■ Control menu ---- icon function description

In full screen state,click video playback window, the screen display control menu.

- ①  ---> Pause       ---> Play
- ②  /  ---> Previous/next tracks
- ③  --->File list
- ④  /  --->Volume+/-
- ⑤  --->Recycle play
- ⑥  --->Random play



## 2 Function operation

### Music function operation

In the main menu state, press **【USB】**  
---> **【Music】** to enter Music interface.

#### ■ Control menu ---- icon function description

In full screen state,click video playback window,  
the screen display control menu.

- ①  ---> Pause       ---> Play
- ②  /  ---> Previous/next tracks
- ③  --->File list
- ④  /  --->Volume+/-
- ⑤  --->Recycle play
- ⑥  --->Random play

## 2 Function operation








### Picture function operation

In the main menu state, press **【USB】** ---> **【Photo】** to enter picture interface.

Gently touch **【☰】** icon, all the picture files from USB will be shown on the left of the screen; Gently touch the pic file name, it will be shown in a small window in middle of screen, after the picture shows for more than 10s without any operation, it will be witched to “ full screenstate ” automatically.

### ■ Control menu ---- icon function description

In full screen state,touch your pictures show window which display control menu bar.

- ①  ---> Pause     ---> Play
- ②  /  ---> Zoom in/zoom out
- ③  ---> Rotate 90 degrees
- ④  ---> Set as the boot screen
- ⑤  ---> File list

## 2 Function operation

### 2.5 Electronic compass function operation

In the main menu press 【COMPASS】 button on the left function interface to enter Electronic compass mode.

Using GPS to set direction. Indicate the direction in the interface.

### 2.6、MHL function operation

Touch 【MHL】 on simulation disc, the rear view will share the mirror on the screen with smart phone.

Smart phone connect with rear view via HDMI/MHL, then change to MHL menu, and the rear view will share the mirror on the screen with smart phone.



# 3 System Setup

## 3.1 Setups menu

In the main menu press **【SETTING】** button on the left function interface to enter system setup main interface.

### ◆ Bright setting

Adjusted Automatic turn off screen (never, 10s, 20s, 60s) and auto brightness, Brightness setup accordingly.

### ◆ Audio setting

Adjusted key tone and microphone volume accordingly.

### ◆ General setting

Time setup: GPS synchronous on/off Adjust the year, month, day, time by choosing move up or move down, 12/24 hour format select.

G-Sensor sensitivity : Adjust the sensitivity of high/medium/low.

SOS : Setup numbers of SOS.

Navigation info: click  /  icon to open/close.

## 3 System Setup

### ◆ Navi setting

Select the NAVI PATH.

### ◆ Other setting

Can choose the settings for “STARTUP LOGO” “MAINTENANCE TIPS”  
“LANGUAGE ”.

VERSION : Display information about the machine.

E-INSTRUSTIONS: Check the operation guide of machine's related  
function.

Touch 【  】 icon to back to main interface, touch 【  】 Icon to back to previous interface.