How to use and control / 如何使用和控制

Filter indicator / 滤器指示灯



- When the orange filter indicator lights on the window completely, remove dust before union."

*To check the filter indicator, adjust to the highest electronic power level and lift nozzle from the floor. ※要检查滤器指示灯、把电子功率调到最高、并将吸端从地板上提起

Caution and maintenance / 注意事项和保养












Direction 使用说明



service agent to repair it.

如果由源线或直空吸尘器受损、请群系制造商或服务机构维修。









Do not use the vacuum cleaner to clean gasoline, benzene, flammable gas or cigarette ash. 请勿用真空吸尘器清洁汽油、苯、易燃气体或煅灰。





flammable materials. 请勿在任何易燃材料附近使用真空吸尘器



vacuum cleaner. 真空吸尘器用过后,总是新开电源插头。



请勿堵塞排气口.









Do not connect the plug with a loose socket, it may cause the melted plug. 请勿将插头接到宽松的插座,否则可能导致插头熔化。



Always disconnect power plug before repairing.



- Always discomment power programmes.
 Use only Hitachi carbon brush.
 If vacuum cleaner is used for cleaning wet surface or outdoor cleaning.

 - it may cause electric shock.

 ・維修前急患無罪用電漏與.

 ・必须使用且立碳刷.

 ・如果用真空吸尘器清洁湿润表面或在户外使用,可能会引起触电事故.

★ Warning: • The appliance is not intended for use by children or infirm person without supervision.

- . Children should be supervised to ensure that they do not play with the appliance • 幼童或虚弱人士若无监护人员请勿使用本电器. • 幼童需有人监护禁止玩弄本电器.

• This product conforms with the safety requirements of council directives IEC60335-1, IEC60335-2-2.

• 本产品符合有关电磁兼容性的欧盟理事会指令 IEC80335-1, IEC80335-2-2


HITACHI

THE HITACHI ATAGO BLDG, bashi 2-chome, Minato-ku, Tokyo, 105-8410 Japan Tel: Tokyo (03) 3502-2111 15-12. Nishi-Shinbashi

3-M2971-2

Instruction Manual 使用说明书


Vacuum Cleaner



Accessories and preparation before use

附件和用前准备





HITACHI

Inspire the Next

Accessories and preparation before use

附件和用前准备




How to assemble nozzle 如何安装吸嘴



How to assemble connector 如何安装连接器

 Align the claw of hose with the connector and push until the "click" sound is heard. 对齐管子和连接器的卡爪并推动,直到发出 "滴答"声。



How to assemble handle 如何安装控制杆

. Align the claw of hose with the handle and push until the "click" sound is heard.

• 对齐管子和控制杆的卡爪并推动,直到发出 "滴答" 声.




How to assemble hose to the unit 如何将管子安装到设备上

• Insert the hose into the connection socket of the unit until the "click" sound is heard. 将管子插入设备的连接接口,直到发出"滴答



To remove, press the lock button and pull out
 若要拆下,按下锁定按钮并拔出。

How to connect handle to the extension pipe 如何连接控制杆和延長導管



How to use and control / 如何使用和控制

Automatic cord rewind / 自动倒线


 Cord rewind
 For automatic cord rewind, press the cord rewind button of the unit. • 要自动倒线,按下设备的倒线按钮。

Direction: If the cord is not rewinded completely, pull the cord slightly. Then press the button once

●使用说明: 如果倒线不彻底,则可先轻拉一下,然后再按一次倒线按钮。

How to control suction power with handle / 如何用控制杆控制吸力





How to use and control / 如何使用和控制



Slide the bag clip out and empty the dust. Clean the bag with wate
 移出袋夹后,清除灰尘,并用水清洗。


(Direction: Regular cleaning of the dust fabric bag will help to prolong product life.

The dust bag should not be machine-washed, and should be hung in the shade to dry before re-use.

●使用说明: 经常清洗集尘布袋能够延长设备的使用寿命。

⚠注意事項: 请勿用洗衣机清洗,应在阴暗处晾干后再使用。





How to assemble the dust bag / $\ensuremath{\mathrm{\muff}}$ $\ensuremath{\mathrm{g}}$

