

CLEVERBOARD 3 with LYNX 4

cleverproducts

The Ultimate Visual Communication Suite

QUICK START GUIDE



LOADING DRIVER SOFTWARE

- Place the Cleverproducts disk (supplied with your board) into your computer.
- From the screen that automatically opens up on screen select “Cleverboard 3 - GO” (this is the driver). Do **NOT** have the computer connected to the board at this time.
- Follow the on screen instructions until “Finish” is displayed.
- Now connect your computer to the board via the USB cable (supplied).
- A new USB device will be detected, Continue to load the second part of the driver until “Finish” is once again displayed.




LOADING LYNX SOFTWARE

- From the same disk supplied with the board now select “Lynx” “GO” and follow the on-screen instructions.
- During the installation you will be asked to type in two sets of licence codes, one for Lynx and one for Wordwall, these can be found on the reverse side of the disk case.
- Note the red “cross” will not change to a green “tick” until all of the code has been entered correctly.



SET UP

- Should look something like this
- Computer to board via USB cable
- Computer to projector via VGA cable
- Image positioned on board



GETTING STARTED

- Check that the batteries in your pen are live by pressing on the pen nib whilst holding the pen to your ear and listening for a high pitched “buzzing sound”
- Ensure that the left hand door is in the open position as this is the “receiver device” which will not see the signal from the pen (transmitter) if closed.
- If you are using the Ink Capture mode refer to the Ink Capture document for the use of this facility.




CALIBRATION

- At the computer refer to the taskbar at the bottom of your screen locate the “Cleverdriver” Icon.
- Right Click on the “Cleverdriver” Icon.
- Select “Settings”
- Ensure that the word “Interactive” is selected from the next box that will appear on screen,
- Select “Calibrate”



CALIBRATION CONTINUED

Clever Driver Icon



Ensure a "Tick" is placed in the "use previous calibration" box.



CALIBRATION CONTINUED

- Once “Calibrate” has been selected the screen will change to a white background with a “cross” inside a “circle” in the left hand corner.
- Take the interactive pen and press with the nib in exactly the centre of the cross.
- Chase the “crosses” around the screen pressing with the pen nib on each one (9 in total). Be accurate and take your time.
- Once the last cross has been selected the screen will change back to “cleverdriver settings” box and you should tick “OK”.
- The board is now calibrated.




LYNX 4 Software


- Double click on the Lynx 4 Icon.
- This will take you into “Workbook” mode
- Your Lynx workbook should look like.....(next page)




LYNX 4 Software




LYNX 4 Software



LYNX 4 Software



LYNX 4 Software



For more detailed information
please contact:

Sahara Presentation Systems

PLC

+44(0) 208 319 7777

cleverproducts
The Ultimate Visual Communication Suite

 **sahara**