instruction manual stainless steel juice extractor

model number: JU4021 after sales support tel: 1300 366 144



Client: ALDI Australia Project: JU4021 Language: EN



 Date:
 23.10.2007

 Version:
 04

 Page:
 1 (of 12 pages)



Stainless Steel Juicer

What your 1 year warranty means

Great care has gone into the manufacture of this product and it should therefore provide you with years of good service when used properly. In the event of product failure within its intended use over the course of the first 1 year after the date of purchase, we will remedy the problem as quickly as possible once it has been brought to our attention. In the unlikely event of such an occurrence, or if you require any information about the product please contact us via our after sales support services, details of which can be found in this manual and on the product itself.

INTRODUCTION

Thank you for purchasing this product from our LUMINA[®] range. We believe that we have provided you with a product that is both reliable and value for money. We encourage you and your friends to choose from our range of LUMINA[®] products again in future.

PACKAGE CONTENTS

- 1 Juicer unit
- 1 Pulp container
- 1 Fruit and vegetable pusher
- 1 Lid with feeding tube
- 1 Removable filter
- 1 Instruction manual
- 2 Warranty stickers
- 1 Warranty certificate

Confirm all parts before disposing of carton.

SAFETY INSTRUCTIONS

- Carefully read this manual before using this appliance.
- Make sure that you know how the appliance functions and how to operate it.
- Maintain the appliance in accordance with the instructions to ensure that it functions properly.
- Keep this manual with the appliance. If the appliance is to be used by a third party, this instruction manual must be supplied with it.
- The safety instructions, by themselves, do not eliminate danger completely, and proper accident prevention measures must always be used.

For any customer query or in the unlikely event of a product failure, please phone or email the helpline contact details below for assistance, before attempting to return the product to the retailer.

Toll Free Help line: 1300 366 144 Email: info@telefixsales.com.au

TABLE OF CONTENTS

| INTRODUCTION 2 |
|-------------------------------|
| PACKAGE CONTENTS2 |
| SAFETY INSTRUCTIONS 2 |
| SAFETY WARNINGS 4 |
| Electrical safety 4 |
| OPERATION GUIDE 5 |
| Parts Guide 5 |
| Assembly Guide5 |
| Preparing For Use |
| Directions For Use |
| Tips |
| Troubleshooting7 |
| Recipes - Introduction 8 |
| Common Questions With Answers |
| Color Source 10 |
| Recipes - Basics 11 |
| CARE AND CLEANING 12 |
| TECHNICAL DATA 12 |

SAFETY WARNINGS



Electrical safety.

- When using electric appliances always observe safety regulations where applicable to reduce the risk of fire, electric shock and personal injury.
- Always check that the power supply corresponds to the voltage on the rating plate.

Supply cord and plug.

- Always fully unwind any cord to avoid overheating.
- Never allow the supply cord to come in contact with hot objects.
- Do not carry the appliance by the cord or yank the cord to disconnect it from the mains supply.
- Disconnect by first switching off the outlet, grasping the plug and pulling it out gently.
- Do not let the supply cord hang over the edge of a table or counter.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid a hazard.

Children.

- Caution. Keep out of reach of children.
- This appliance is not intended for use by young children or infirm persons.
- Young children must be supervised to ensure that they do not play with the appliance.
- This appliance is not suitable for use by young children or infirm persons unless adequately supervised to ensure that they can use the appliance safely.

Water.

- Do not immerse. Do not immerse any part of this appliance motor assembly or supply cord in water or other liquid.
- Do not use with wet hands or use in damp situations.

Handling.

- Do not drop the appliance.
- Do not use this appliance if it has been damaged in any way, immersed in water, the supply cord is damaged or the operation is faulty.
- Contact with any damaged appliance could result in electric shock.
- Check the filter every time you want to use the appliance. If you detect any cracks or damage, Do not use the appliance if the filter is damaged.
- Make sure all parts are correctly mounted before you switch on the appliance.
- Only use the appliance when the clamp is locked.
- Never reach into the feeling tube with your fingers or with an object while the appliance is running. Only the pusher is to be used for this purpose.
- Only unlock the clamp after you have switched the appliance off and the filter has stopped rotating.

Unattended.

• Do not leave the appliance unattended while in use. Disconnect from the power supply.

Sharp objects and moving parts.

- **WARNING!** Do not touch the small cutting blades in the base of the filter. The cutting blades have very sharp edges.
- Do not operate near any body parts. Ensure the blades have stopped rotation completely before touching any area near the blades.

Store in a safe place.

• When not in use store your appliance and all its accessories and instruction manual in a safe and dry place.


Liability.

• No liability can be accepted for any damage or personal injury caused by noncompliance with these instructions or any other improper use or mishandling. This appliance is intended for household use only.

This appliance has been designed for general indoor household use only. Disconnect from the power supply when not in use.

Parts Guide

- A. Plunger
- **B.** Feeding Tube
- C. Lid
- **D.** Filter
- E. Juice Collector
- F. Driving Shaft (Do not remove)
- G. Motor Unit
- H. Spout
- I. Control Knob
- J. Clamps
- K. Pulp Container



Assembly Guide

Important Note: Maximum Use

WARNING! This appliance has been designed for short-term use only. Refer below guide for usage times.

• Juicer Use - Do not operate the juicer for more than 40 seconds at a time when juicing heavy loads, allowing sufficient cool down time between uses.

CAUTIONS!

- Sharp Blades. Handle with care. Do not touch moving blades in the base of the filter.
- Unattended. Unplug when not in use or before assembly or disassembling.
- Safety Warnings. Read all safety warnings before use.

Client: ALDI Australia Project: JU4021 Language: EN
 Date:
 23.10.2007

 Version:
 04

 Page:
 6 (of 12 pages)

Preparing For Use

- 1. Make sure your glass or pitcher sits under the spout to collect the juice.
- 2. Place the pulp container into the appliance by tilting it forwards slightly. Insert the top end first and then push down the bottom end.
- 3. Place the juice collector into the appliance. Make sure the rim is flush with the motor unit.

NOTE: While you are preparing juice, you can empty the pulp container by switching the appliance off and carefully removing the pulp container. Reassemble the empty pulp container before you continue juicing.


- 4. Put the filter in the juice collector. Make sure the filter is fitted securely onto the driving shaft. The blade should sit below the rim of the pulp container when in place.
- 5. Hold the lid over the filter and lower it into position.
- 6. Snap the two clamps onto the lid to lock it into place. (You will hear a click). NOTE: Make sure the clamp is locked into position on both sides of the lid.
- 7. Slide the pusher into the feeding tube by aligning the groove in the pusher with the small protrusion on the inside of the feeding tube.


Directions For Use


- 8. Knob:
 - Off
 - Position 1 Standard Speed (For most fruits &
 - vegetables)
 - Position 2 High Speed (For hard skin & tough foods)


The juicer will only function if all parts have been properly assembled and the lid has been properly locked in place with the clamps.


9. For oversized pieces, wash the fruit and/or vegetables and cut them into pieces that fit into the feeding tube.




















ALDI Australia Client: **Project**: JU4021 Language: EN

7

23.10.2007 Date: Version: 04 Page: 7 (of 12 pages)

10. Put the pieces in the feeding tube and gently press them towards the rotating filter with the pusher.NOTE: Do not exert too much pressure on the pusher, as this could affect the quality of the juice and damage the filter.

10

After you have processed all ingredients and the juice flow has stopped, switch the appliance off and wait until the filter has stopped rotating.

Tips

- Use fresh fruit and vegetables, as they contain more juice. Pineapples, beetroots, celery stalks, apples, cucumbers, carrots, spinach, melons, tomatoes, pomegranates, oranges and grapes are particularly suitable for processing in the juicer.
- You do not have to remove thin peels or skins. Only thick peels, e.g. those of oranges, pineapples and uncooked beetroots need to be removed. Also remove the white pith of citrus fruits because it has a bitter taste.
- When preparing apple juice, remember that the thickness of the apple juice depends on the kind of apple you are using. The juicier the apple the thinner the juice. Choose a kind of apple that produces the type of juice you prefer.
- Apple juice turns brown very quickly. You can slow down this process by adding a few drops of lemon juice.
- Fruits that contain starch, such as bananas, papayas, avocados, figs, and mangos are not suitable for processing in the juicer. Use a food processor, blender or bar blender to process these fruits before adding them into the juicer.
- Leaves and leaf stalks, e.g. lettuce, can also be processed in the juicer.
- Drink the juice soon after you have extracted it. If it is exposed to air for some time, the juice will lose its taste and nutritional value. Place in sealed container, to extend taste and nutritional value.
- To extract the maximum amount of juice, always press the pusher down slowly.
- The juicer is not suitable for processing very hard and/or fibrous/starchy fruits or vegetables such as sugar cane.

| Problem | Solution |
|---|--|
| The juicer does not work. | The juicer is equipped with a safety system. It will not work if the parts have not been mounted properly. Check whether the parts have been assembled in the right way, but switch off the juicer before you do so. |
| The motor unit gives off an unpleasant smell the first few times the appliance is used. | This is not unusual. If the appliance continues to give off this smell after a few uses, check the quantities you are processing and the processing time. |
| The filter is blocked. | Switch the appliance off, clean the feeding tube and the filter, and process a smaller quantity. |
| The filter touches the feeding tube or vibrates strongly during processing. | Switch the juicer off and unplug it. Check if the filter has been properly placed in the juice collector. The ribs in the bottom of the filter should fit properly onto the driving shaft. Check if the filter is damaged. |

Troubleshooting

Recipes - Introduction

Freshly squeezed juices are an easy yet refreshing way to stay healthy and increase your intake of fruits and vegetables. The juicer will not only allow you to have the best tasting treats and drinks, it will provide high nutritional value to your diet. If you like the amazing taste of fresh juice, it doesn't get any better than this. Thank you and enjoy juicing!

To help you get started, we have provided you with the following:

Hints & Tips

In order to get the most out of your JUICING, we highly suggest that you review this section before you get started.

Recipes

Included are basic recipes. We also encourage you to come up with your own!

Before you begin using your juicer, there are a number of things you should consider in order to get the most out of your juicer.

- We strongly suggest using fresh fruits & vegetables. When they are in season, they taste better.
- Push the food plunger slowly so you can extract the maximum amount of juice.
- We suggest peeling any fruits or vegetables that have a "rough" skin .
- The juicer is best used when you have removed as many seeds and pits as possible prior to juicing.
- Cleaning can be made easier by placing a plastic bag in the waster collection container.
- Do not pour liquids through the juicer.
- Do not use fruits or vegetables when they are at the height of ripeness.
- Do not freeze juice or pulps longer than one month.
- We suggest only leaving your juice refrigerated for 1 day, after that it begins to sour.
- Bundle herbs, sprouts, and leafy green vegetables together for best results. You can even wrap them in a lettuce leaf.
- Root ginger adds great taste to all sorts of juice recipes.
- It is best to store fruits and harder vegetables at room temperature. More delicate foods should be refrigerated.
- Feel free to empty the pulp container while juicing just make sure you turn the juicer off.

We strongly advise not to juice the following: Avocado, Rhubarb, Leek, Eggplant, Winter Squash, Banana, Coconut, Figs, Mango, or Papaya. Use a Food Processor or Blender to process.

By eating a variety of colorful fruits and vegetables (green, yellow/orange, red, blue/purple, and white) you are giving your body a wide range of nutrients that are important for good health. Each color offers something unique, like different vitamins, minerals, and disease-fighting phytochemicals, which work together to protect your health.

Common Questions With Answers

| Question | Answers |
|---|---|
| Do I need to prepare fruits and vegetables for juicing? | Yes, but preparation is minimal. Simply wash all fruits and vegetables thoroughly before use, peel any fruits with hard skin, and remove seeds and pits. |
| Is there any order for juicing fruit and vegetables? | When juicing a variety of fruits and vegetables, always alternate between soft and hard ingredients. Hard fruits, such as apples, clean out the micromesh filter, enabling the next item to be extracted efficiently. Always end with a hard fruit as this makes cleaning the mesh filter basket very easy. |
| Can I juice the whole orange? | Oranges and other citrus fruits can be juiced whole, but always peel them first. For extra-frothy orange juice, keep your oranges in the fridge before juicing. |
| What can I do with the residual pulp? | The pulp left from juicing is rich in fiber, vitamins, and minerals. It can be used to bulk out hamburger patties and thicken up soups and casseroles. Pulp will also add flavor to muffins, flans, mousse, strudel and cakes. You can even use pulp in the garden as compost. Regular juicers will create enough pulp for a worm-farm. |
| Can I store freshly squeezed juice in the refrigerator? | All freshly squeezed juices are best consumed immediately after juicing - the longer they sit the more nutrients they lose. Juice is most delicious when fresh. |
| Are the Juicer parts dishwasher safe? | The juice cover, filter bowl, pulp container, stainless steel filter basket, and juice pitcher can all be placed in the dishwasher (on the top shelf only). Alternatively, keep your juicer clean by rinsing all of the removable parts under running water immediately after use. |

Recipes - Basics

| Tomato Juice | Apple Juice |
|---|--|
| 3.5 lbs. of fresh, ripe, firm tomatoes; washed, no stems or leaves Process ingredients through juicer. Serve immediately! Spicy: Add a few stalks of celery with leaves (washed) and fresh ground pepper to taste. Sweet: Add sugar for sweet tomato juice. TIP: Fresh tomato juice can be pale, pink & frothy since it has no additives, coloring, or preservatives. | • 4 large apples, washed with stems removed Process through the Juicer. Serve immediately! TIP: Mix apple varieties for best flavor. Add a carrot for a sweet difference & vitamin boost. Spice it up with a sprig of mint or a slice of ginger. |
| Island Blend | Afternoon Delight |
| 1 pineapple sliced, top & skin removed 1 papaya, sliced & seeds removed (process in blender) 1 large orange, peeled 1 mango, peeled & pitted (process in blender) 1 guava, peeled & pitted Process pineapple, orange, and guava through the Juicer. Add papaya and mango, enjoy! | 1 orange, peeled 1 sweet apple, washed & stem removed 1 large carrot, washed, topped & tailed 1 grapefruit, peeled 1/2 cantaloupe, remove rind & seeds or 1 pear, washed Juice apple & carrot first, and then juice the remaining ingredients. Serve immediately! |
| Good Morning Juice | Wild Watermelon |
| 1 bunch red grapes, washed 3 slices pineapple, top removed & skinned 1/2 orange, peeled 5 fresh strawberries, washed Process through the juicer. Serve immediately! | 1 chopped, seeded watermelon, skin removed 1 container strawberries, hulled 1 cup papaya, peeled and seeded (process in blender) Process watermelon and strawberries through the juicer. Add papaya and serve immediately! |
| Carrot Fruit Juice | Pineapple Juice |
| 4 large carrots, washed, & topped & tailed 2 sweet apples (such as red or golden delicious), washed & stems removed Process through the juicer. Serve immediately! | 4 pineapple spears, top removed & skinned 1 medium orange, peeled Process through the juicer. Serve immediately! |
| Grape Juice | Vegetable Blend |
| 1 bunch seedless white or red grapes, washed & stemmed Process through the juicer. Serve immediately! | 1 large carrot, washed, topped & tailed 1 small wedge of lemon, peeled & seeded 1 head of celery, washed Process through the juicer. Serve immediately! |

CARE AND CLEANING

Before Cleaning.

• When not in use or before cleaning, always disconnect the appliance from the mains supply.

Cleaning Guide.

- Regularly clean the outside of the main Juicer Unit Body with a soft damp cloth and dry it with a dry towel.
- WARNING! Do not immerse any part of the main Juicer Unit Body in water.
- The juicer is easier to clean if you do so immediately after use.
- Do not use abrasive cleaning agents, scourers, acetone, alcohol etc. to clean appliance.
- All detachable parts are dishwasher safe.
- 1. Switch the juicer off, remove the plug and wait until the filter has stopped rotating.
- 2. Remove the dirty parts from the motor unit. Disassemble the juicer in the following order:
- Remove the pulp container
- Remove the pusher
- Open the clamps
- Remove the lid
- 3. Remove the juice collector together with the filter.
- 4. Clean these parts with the cleaning brush in warm water with a mild detergent.
- 5. Clean the motor unit with a damp cloth.

Storage

• When not in use store the appliance, accessories and these instructions in a dry place.

TECHNICAL DATA

 Supply Voltage:
 220-240 V ~ AC 50-60 Hz

 Wattage:
 500-700 Watt



12

