


ENGLISH

3 Hand with Date

(Model 715)



Setting the time

1. Pull crown out to position III (the watch stops).
2. Turn crown until you reach the correct time.
3. Push crown back to position I.


Setting the date

1. Pull crown out to position II (the watch continues to run).
2. Turn crown until yesterday's date appears.
3. Pull crown out to position III (the watch stops).
4. Turn crown until correct date appears.
5. Continue to turn crown until correct time appears.
6. Push crown back to position I.

Do not change the date between the hours of 10pm and 2am. This is the time when the movement is in position to carry out the automatic date change, and any interference may cause damage to the movement.

3 Hand with Day and Date

(Models 517 and 507)



Setting the time

1. Pull crown out to position III (the watch stops).
2. Turn crown until you reach the correct time.
3. Push crown back to position I.


Setting the day and date

1. Pull crown out to position II (the watch continues to run).
2. Turn crown clockwise to set the date. Set to the previous day.
3. Turn crown counter-clockwise to set the day. Set to the previous day.
4. Pull crown out to position III (watch stops).
5. Continue to turn crown until correct time appears.
6. Push crown back to position I.

Do not change the date between the hours of 10pm and 2am. This is the time when the movement is in position to carry out the automatic date change, and any interference may cause damage to the movement.

Chronograph 2 Eye

(Models 5021.D)



Setting the time


1. Pull crown out to position III (the watch stops).
2. Turn crown until you reach the correct time.
3. Push crown back to position I.

Setting the date

1. Pull crown out to position II (the watch continues to run).
2. Turn crown until yesterday's date appears.
3. Pull crown out to position III (the watch stops).
4. Turn crown until correct date appears.
5. Continue to turn crown until correct time appears.
6. Push crown back to position I.

Chronograph

- The minute counter measures 30 minutes per rotation.
- The center stop-second measures 60 seconds per rotation.



Please note:

Before using the chronograph functions, please ensure that:

- *the crown is in position I (= normal position).*
- *the two chronograph hands are precisely at zero position following activation of pusher B. Should this not be the case, the positions of the hands must be adjusted (see the chapter entitled "Adjusting the chronograph hands to zero position").*

Chronograph: Basic function

(Start / Stop / Reset)

1. Press pusher A to start the center stop-second hand.
2. To stop the timing, press pusher A again.
3. To reset the two chronograph hands to zero positioning, press pusher B.

Chronograph: Intermediate or interval timing

1. Press pusher A to start the center stop-second hand.
2. Press pusher B to stop the chronograph.

**Note: Although the chronograph hands have stopped, the movement continues to record the current timing.*


3. Make up the measured time:
Press pusher B again and the 2 chronograph hands are quickly advanced to the ongoing measured time. To continue to record intervals, continue to push pusher B.
4. Press pusher A to stop and the final time is displayed.
5. To reset the two chronograph hands to zero positioning, press pusher B.

Adjusting the chronograph hands to zero position

1. Pull crown out to position III (the two chronograph hands are in their correct or incorrect zero position).
2. Keep pushers A and B depressed simultaneously for at least 2 seconds (the center stop-second rotates by 360° - corrective mode is activated).
3. Press pusher A to single step the center stop-second hand. Press and hold pusher A to advance the center stop-second hand quickly. Press pusher B to advance to the next hand.
4. Press pusher A to single step the minute counter hand. Press and hold pusher A to advance the minute counter hand quickly.
5. Return the crown to position I.

Chronograph 3 Eye

(Models 5030.D)



Setting the time


1. Pull crown out to position III (the watch stops).
2. Turn crown until you reach the correct time.
3. Push crown back into position I.

Setting the date

1. Pull crown out to position II (the watch continues to run).
2. Turn crown until yesterday's date appears.
3. Pull crown out to position III (the watch stops).
4. Turn crown until correct date appears.
5. Continue to turn crown until correct time appears.
6. Push crown back into position I.

Chronograph

- The chronograph's hour counter measures times up to 12 hours.
- The minute counter measures 30 minutes per rotation.
- The center stop-second measures 60 seconds per rotation.



Please note:

Before using the chronograph functions, please ensure that:

- the crown is in position I (= normal position).
- the three chronograph hands are precisely at zero position following activation of pusher B. Should this not be the case, the positions of the hands must be adjusted (see the chapter entitled "Adjusting the chronograph hands to zero position").

Chronograph: Basic function

(Start / Stop / Reset)

1. Press pusher A to start the center stop-second hand.
2. To stop the timing, press pusher A again.
3. To reset the three chronograph hands to zero positioning, press pusher B.

Chronograph: Intermediate or interval timing

1. Press pusher A to start the center stop-second hand.
2. Press pusher B to stop the chronograph.

**Note: Although the chronograph hands have stopped, the movement continues to record the current timing.*


3. Make up the measured time:
Press pusher B again and the 3 chronograph hands are quickly advanced to the ongoing measured time. To continue to record intervals, continue to push pusher B.
4. Press pusher A to stop and the final time is displayed.
5. To reset the three chronograph hands to zero positioning, press pusher B.

Adjusting the chronograph hands to zero position

1. Pull crown out to position III (all three chronograph hands are in their correct or incorrect zero position).
2. Keep pushers A and B depressed simultaneously for at least 2 seconds (the center stop-second rotates by 360° - corrective mode is activated).
3. Press pusher A to single step the center stop-second hand. Press and hold pusher A to advance the center stop-second hand quickly. Press pusher B to advance to the next hand.
4. Press pusher A to single step the hour counter hand. Press and hold pusher A to advance the hour counter hand quickly. Press pusher B to advance to the next hand.
5. Press pusher A to single step the minute counter hand. Press and hold pusher A to advance the minute counter hand quickly.
6. Return the crown to position I.

Chronograph 3 Eye

(Model ETA G10)



Setting the time


1. Pull crown out to position III (the watch stops).
2. Turn crown until you reach correct time.
3. Push crown back into position I.

Setting the date

1. Pull crown out to position II (the watch continues to run).
2. Turn crown until yesterday's date appears.
3. Pull crown out to position III (the watch stops).
4. Turn crown until correct date appears.
5. Continue to turn crown until correct time appears.
6. Push crown back into position I.

Chronograph

- The chronograph's hour counter measures times up to 12 hours.
- The minute counter measures 30 minutes per rotation.
- The center stop-second measures 60 seconds per rotation.



Please note:

Before using the chronograph functions, please ensure that:

- the crown is in position I (= normal position).
- the three chronograph hands are precisely at zero position following activation of pusher B. Should this not be the case, the positions of the hands must be adjusted (see the chapter entitled "Adjusting the chronograph hands to zero position").

Chronograph: Basic function

(Start / Stop / Reset)

1. Press pusher A to start the center stop-second hand.
2. To stop the timing, press pusher A again.
3. To reset the three chronograph hands to zero positioning, press pusher B.

Chronograph: Intermediate or interval timing

1. Press pusher A to start the center stop-second hand.
2. Press pusher B to stop the chronograph.

**Note: Although the chronograph hands have stopped, the movement continues to record the current timing.*


3. Make up the measured time:
Press pusher B again and the 3 chronograph hands are quickly advanced to the ongoing measured time. To continue to record intervals, continue to push pusher B.
4. Press pusher A to stop and the final time is displayed.
5. To reset the three chronograph hands to zero positioning, press pusher B.

Adjusting the chronograph hand to zero

1. Pull crown out to position II (all 3 hands are in their correct or incorrect position).
2. Press pusher A to single step the 1/10 second hand. Press and hold pusher A to advance the 1/10 second hand quickly.
3. Press pusher B to single step the center stop-second hand. Press and hold pusher B to advance the center stop-second hand quickly.
4. Pull out crown to position III.
5. Press pusher A to single step the minute counter hand. Press and hold pusher A to advance the minute counter hand quickly.
6. Return the crown to position I.

24-Hour 4 Hand

(Model 515.24 H)



Setting the time

1. Pull crown out to position III (the watch stops).
2. Turn crown until you reach the correct time.
3. Push crown back into position I.


Note: While crown is in position III, the 24-hour hand will rotate simultaneous with the minute and hour hand.

Setting the 24-hour hand

1. Pull crown out to position II.
2. Turn crown in the counter-clockwise direction until the 24-hour hand shows the current time on the fixed bezel.
3. Push crown back into position I.

GMT - 4 Hand - World Time

(Model 515.24 H)



Crown A

I = normal position, crown completely pushed in
II = city setting

Crown B

I = normal position, crown completely pushed in
II = clockwise: date setting, counter-clockwise: 24-hour hand setting
III = time setting

Setting the time

1. Pull crown B out to position III (the watch stops).
2. Turn crown B until you reach the correct time.
3. Push crown B back to position I.

Note: While crown B is in position III, the 24-hour hand will rotate simultaneous with the minute and hour hand.

Setting the 24-hour hand

1. Pull crown B out to position II.
2. Turn crown B in the counter-clockwise direction until the 24-hour hand shows the current time on the fixed bezel.
3. Push crown B back to position I.

Setting the city ring


1. Pull crown A out to position II.
2. Turn crown A to align the local city with the 24-hour hand.
3. Push crown A back to position I.
4. All cities are now aligned with the appropriate times.

Note: It is important to set the 24-hour hand before setting the city time.

Tachymeter Usage

The Tachymeter function is used to measure the rate of speed of an object over a fixed distance. The scale, located either on the top ring or the inside bezel of the timepiece, will display speed in Miles, Knots, or Kilometers per hour.

Example of usage: In a driving race, the car passes the first mile (km) post when the seconds hand is at the 12:00 position (60 second mark). Commence measurement. At the 35 second mark the car passes the second mile (km) post, you will see that the car travelled a distance of one mile at 100 miles (km) an hour.



Automatic Winding Movement

A timepiece fitted with an automatic winding movement obtains the power to wind itself by the movement of your wrist. It is important that your timepiece is adjusted to match the size of your wrist. A loose fit may result in a loss in capacity of the timepiece to wind itself. When fully wound, your timepiece has a power-reserve of approximately 42 hours. If the timepiece has not been worn for over 42 hours it is advised that it be manually wound to ensure necessary power-reserve.

Water Resistance

All Zodiac timepieces are designed with a minimum water-resistance rating of 3ATM (100ft/30m).

The water-resistance of a timepiece protects the movement from, dust, moisture, and risk of damage to the movement should it be immersed in water.

Please see chart for guidelines for recommended exposure of various water ratings.

It is important not to attempt to adjust the position of the crown while the timepiece is in contact with water. Water can enter the case causing damage to the movement.

For timepieces with screw-down crowns, it is important to ensure the crown is in the proper position and completely locked before contact with water.

For timepieces with chronograph functions, do not engage the chronograph under water, as water may leak in the case and cause damage to the movement.

All Zodiac timepieces are designed to withstand use as indicated on line 1 of the following chart.

Use Precautions

Resistance to Water

Indication		Water-related Use			
	Water-resistant characteristics	Light spray perspiration, light rain, etc.	Bathing, etc.	Swimming, etc.	Skin diving, (Diving without oxygen cylinder)
1	3 ATM	OK	NO	NO	NO
2	5 ATM	OK	OK	NO	NO
3	10 ATM	OK	OK	OK	NO
4	20 ATM	OK	OK	OK	OK
5	30 ATM	OK	OK	OK	OK
Always set the crown in the normal position. Tighten screwlock crown completely.					

Care and Precautions

Each Zodiac timepiece is designed and manufactured to exceed the highest of standards. Unlike most other mechanical objects, a watch operates non-stop. In order to ensure optimal performance and longevity from your timepiece, please review the simple guidelines for care and precautions of your new Zodiac timepiece.

Care

Your timepiece should be cleaned with a soft cloth and water only. Do not submerge your timepiece. Your timepiece should be rinsed clean and dried with a soft cloth after any saltwater use. In order to maintain the “new look” of metal bracelets, we recommend periodic cleanings of the bracelet. Dip a soft brush in warm soapy water and gently rub bracelet clean. We advise having your timepiece serviced every 18-24 months to ensure long use and trouble free operation.

Precautions

Your timepiece is a complex integration of parts and components brought together by skilled craftsmen. There are certain actions or environmental situations that may damage or impede your timepiece’s ability to perform optimally.

It is important to avoid the following conditions: extreme heat or cold, as well as prolonged periods of exposure to direct sunlight, exposure to wet conditions that exceed your timepieces’s water rating (see case back and chart). Never operate any of the function buttons or crown when timepiece is in contact with water.

Your timepiece should not be affected by magnetic fields generated by household items such as televisions and stereos, but avoidance of other strong electric fields or static electricity, which may interrupt mechanism, is suggested. It is also important to avoid extreme shock or impact.