الفجر ن ALFAJR



www.alfajr.com

WR-02

MAIN FEATURES

· Azan times for 250 cities New cities can also be programmed Five different methods to calculate Azan times

 Prayer reminders (independently set before or after azan times)

· Qur'aan bookmark for last read Sura name and Verse number

Qibla direction from the North

Daylight saving time option

English and Arabic languages

Full screen EL light

Hijri and Gregorian calendars

Stop Watch

Two daily alarms

Water resistant

2

MAIN MENU

Main Screen:




Note: To set time, Gregorian calendar and your city press and hold 5ET for a while at main screen. To set Hijri calendar or any prayer alarm, move to the desired screen then press 5ET.

4

Setting Time, Calendar and City

Main Screen



Note: When adjusting hours, notice the flashing AM or PM.

MAIN MENU (Cont.)

3

[1]



Note: The watch will automatically go back to the main screen after few seconds (if buttons are not pressed).

Setting Time, Calendar, and City (Cont.)

(5)

11111111

₩ QIBLE



MECCA

YEAR


JANUARY

Note: After selecting any city that uses Daylight Saving Time (DST), the DST option screen will appear before Qibla screen.

6

SETTING HIJRI CALENDAR

To set Hijri calendar, move to Hijri calendar screen (by pressing +), then:



Note: When the Hijri calendar is set, the Gregorian calendar is not affected. However, after setting the Gregorian calendar, the Hijri calendar will be readjusted according to the astronomical moon sighting at Mecca.

SETTING PRAYER ALARMS

Prayer alarms are useful to remind you of Iqama or Salat time. Each prayer alarm can be set to ring before or after the azan time by any interval. Each alarm duration can be adjusted (in seconds), or can be turned off. The icon 🙂 near an azan time indicates that the prayer alarm is ON (for that particular azan).


Example: To set Zuhor prayer alarm to always ring after the azan by 10 minutes, move to Zuhor azan screen, then



Note: When you buy the watch, prayer alarms will ring exactly at the azan times.



ADVANCED MENU



10 ADVANCED MENU DESCRIPTION

ALARM I

Alarm 1 is a daily general purpose alarm. Its setting is similar to the prayer alarms setting (page 7). The $({\bf 0} \ \, {\bf icon} \, \, {\bf indicates} \, {\bf that} \, {\bf it} \, {\bf is} \, {\bf ON}.$

ALARM I .12:00 "

Alarm 2 is another daily alarm similar to alarm 1. The activation of this alarm is indicated by the small \bullet) icon.

LANGUAG

Language selection: English or Arabic.

TAQWEEM

The watch uses the local taqweem or the most widely used system in your city. Other available taqweems: Um Alqura, Egypt, Islamic world organization, ISNA, and Islamic scientific university [Hanafi system].

12 ADVANCED MENU DESCRIPTION (Cont. 2)

MAIN CA

Main Calendar: either the Gregorian or the Hijri calendar can be displayed in the main screen.

DST SEI

Daylight Saving Time (DST) selection. When this option is turned ON, all azan times will increase by one hour.

UUU.ALF

Our web page address: www.alfajr.com

Note: The watch will automatically go back to the main screen after few seconds. But to quickly go back to the main screen, press and hold + for two seconds.

14 QURAN BOOKMARK




Quran bookmark screen displays the last Sura name and Verse number read. To reach this screen, press $\, + \,$ then again press and hold $\, + \,$ for 2 seconds. To change the bookmark, use $\, + \,$ or $\, - \,$.

IMPORTANT COMMENTS

- 1/ After setting any city, the Qibla direction from the North is displayed. The 🕇 arrow indicates North, 🥒 indicates Northeast, etc.
- 2 Over 250 cities around the world are programmed in this watch. To program any new city, follow the steps on page 13.
- 3/ If azan times are not correct, check the following: city selection, Gregorian calendar, DST option, and select the appropriate taqweem. Note that azan times may differ by few minutes in some cases.
- 4/ The next azan time is displayed at the bottom of the screen, and it is updated after 30 minutes from current azan time.

ADVANCED MENU (Cont.)



ADVANCED MENU DESCRIPTION (Cont. 1)

[11]

level

(9)

STOP-W

Stop Watch with accuracy 1/10 second. Press 5ET to enter and exit, press + for Start/Stop, and press — to reset to 00:00

VOLUME

Three volume levels (for all alarms): 2 is High, 1 is Low, or OFF.

TIME DI

Time display: time format in main screen (hours: minutes: seconds) can be displayed with or without seconds. You can also hide or display the coming azan time in the main screen.



The expected battery life is more than a year. The Cr2016 battery, used in this watch, should be replaced when the level reaches

Battery level in Volts can also be displayed, by pressing 5ET

PROGRAMMING NEW CITY

13

Any city around the world can be programmed. For example, the following steps show how to program the city of Taif with (GMT+3); located on Latitude 21 $^{\circ}$ 15 $^{\circ}$ N and Longitude 40 $^{\circ}$ 20 $^{\circ}$ E.

- $1/\,\,$ Follow the steps on pages 4 and 5 till you get to city selection
- 2/ Press + or to choose NEWCITY then press SET
- 3/ Adjust latitude ($21\,N$), press 5ET, adjust minutes (15), then press 5ET
- 4/ Adjust longitude (40~E), press SET, adjust minutes (20), and press SET
- 5/ Adjust GMT(+3) then press SET
- 6/ Adjust daylight saving time (DST OFF) and press SET
- 7/ the watch will display Qibla direction and will calculate new azan times .

Note: If azan times are not correct, check the following: city's coordinates, Gregorian calendar, DST option, and select the appropriate taqweem.